

M4500 User's Manual

Systems Engineering Associates, Inc.
14989 West 69th Avenue
Arvada, Colorado 80007 U.S.A.
Telephone: (303) 421-0484
Fax: (303) 421-8108
www.sea-seg.com

02/2004

M4500 User's Manual

Copyright © 1995 Systems Engineering Associates, Inc.

All Rights Reserved!

WARNING

To ensure the equipment described by this User Manual, as well as the equipment connected to and used with it, operates satisfactorily and safely, all applicable local and national codes that apply to installing and operating the equipment must be followed. This includes the National Electric Code in the USA and other applicable legislation, regulations, and codes in practice elsewhere. Since codes can vary geographically and can change with time, it is the user's responsibility to determine which standards and codes apply, and to comply with them.

FAILURE TO COMPLY WITH APPLICABLE CODES AND STANDARDS CAN RESULT IN DAMAGE TO EQUIPMENT AND/OR SERIOUS INJURY TO PERSONNEL.

Persons supervising and performing installation or maintenance must be suitably qualified and competent in these duties, and should carefully study this User Manual and any other manuals referred to by it prior to installation and/or operation of the equipment.

—

The contents of the User Manual are believed to be correct at the time of printing; however, no responsibility is assumed for inaccuracies. In the interests of a commitment to a policy of continuous development and improvement, the manufacturer reserves the right to change the specification of the product or its performance or the contents of the User Manual without notice.

—

Copyright © 2001 Systems Engineering Associates, Inc.

All Rights Reserved !

CONTENTS

1. General Description	1
1.1 PLC Section	1
1.2 PLS Section	2
1.3 Interrupt Inputs	3
1.4 Analog I/O	3
1.5 Display/Keypad	4
1.6 Serial Communications Board	5
1.7 Digital I/O Boards	5
1.8 Diagnostics/Fault Detection	5
1.9 LED Status Indications	6
 2. PLC Features	 7
2.1 PLC Program Structure	7
2.2 Special Function Variables (SFVs – directly addressed)	8
2.3 Special Function Variables (SFVs – indirectly addressed)	10
2.4 Memory mapped I/O	11
 3. PLS Features	 13
3.1 Standard PLS Features	13
3.1.1 Timing Channels	13
3.1.2 Scale Factor	13
3.1.3 Offset (electronic zero)	13
3.1.4 PLS Programs	14
3.1.5 Speed Compensation	14
3.2 Advanced PLS Features	15
3.3 PLS Programming	16
3.4 Implementing M4500 as a Stand-Alone PLS	17
 4. PLS Programming Using the Keypad/Display	 19
4.1 Channel Set-Point Programming Commands	19
4.2 PLS Configuration Parameters	19
4.3 PLS Key Definitions	20
4.4 PLS Display Fields	21
4.5 Setting the PLS Configuration	21
4.6 Selecting a New Channel Number	23
4.7 Single SET-POINT Programming Command	23
4.8 PULSE TRAIN Programming Command	24
4.9 CLEAR CHANNEL Command	25
4.10 Searching (recalling) a Channel	25

5. PLS Programming Using SYSdev	27
5.1 PLS Features of SYSdev	27
5.2 PLS Menus	28
5.2.1 Main Development Menu	28
5.2.2 Channel Edit Menu	32
5.3 PLS Configuration	34
5.3.1 PLS Program	34
5.3.2 Scale Factor	35
5.3.3 Number of PLS Channels	35
5.3.4 Speed Compensation	35
5.4 Channel Set-Point Programming Commands	35
5.4.1 Single Set-Point Programming Command	36
5.4.2 Fine Tune Set-Point Command	37
5.4.3 Pulse train Command	38
6. Fault Detection	39
6.1 Fault Routine Execution	39
6.2 Viewing Fault Codes with SYSdev	39
6.3 Fault Codes	41
6.3.1 Watchdog Timer Timeout (40H)	41
6.3.2 IBM PC to M4500 Communications Failure (42H)	42
6.3.3 Invalid Program Faults (5cH and 5dH)	42
6.3.4 User Program sfunc09 System Fault Call (45H)	43
6.3.5 Internal M4500 Faults (44H, 59H-5bH)	43
6.4 Serial Network Communications Errors	43
6.4.1 Serial network Comm error Codes	44
6.4.2 No Response from Slave (04H and 05H)	44
6.4.3 Serial Network Integrity Error (03H, 06H-0eH, 10H)	45
6.4.4 Address Outside Range (0fH)	45
7. Hardware Confidence Test	47
7.1 Tests Performed	47
7.2 Performing the Hardware Confidence Test	48
7.2.1 Equipment Required	48
7.2.2 Executing the Test	49

CONTENTS

8. Installation	51
8.1 Mounting the D4590/D4591 Keypad/Displays	51
8.1.1 Installing the Keypad Legend Behind the Overlay	51
8.1.2 Mounting the Keypad/Displays in the Cabinet Door	52
8.2 Mounting the M4500 Chassis	55
8.2.1 Installing the Optional Circulation Fan	55
8.2.2 Back-Panel Mounting the M4500 Chassis	55
8.2.3 Door Mounting the M4500 Chassis	55
8.3 Mounting the P4500 Power Supply	57
8.4 Installing I/O Boards in the M4500 Chassis	57
8.5 Wiring the Interrupt Inputs	58
8.6 Wiring the Analog I/O	59
8.7 Wiring the Fault Interlock	60
8.8 Serial Network Installation	61
8.8.1 Wiring the Serial Network	61
8.8.2 Setting the Network Address	63
8.9 Resolver Interface	63
8.9.1 Resolver Wiring	64
8.10 Power-Up Sequence of M4500 Modules	66

LIST OF FIGURES

Figure 4.1 – PLS Keypad Assignments	20
Figure 8.1 – D4590/D4591 Keypad Display Bezel Removal	53
Figure 8.2 – D4590 Keypad/Display Recommended Panel Cut-out	54
Figure 8.3 – D4591 Keypad/Display Recommended Panel Cut-out	54
Figure 8.4 – M4500 With Keypad/Display Door Mount Detail	56
Figure 8.5 – Typical Interrupt Wiring	58
Figure 8.6 – Typical Analog I/O Wiring	59
Figure 8.7 – Typical Fault Interlock Wiring	60
Figure 8.8 – Typical Network Wiring	62
Figure 8.9 – Alternative Serial Connector Wiring	62
Figure 8.10 – M4500 Resolver Interface (stand alone)	65
Figure 8.11 – Two M4500's Slaved to One Resolver	65

CONTENTS

APPENDICES

I/O Board Data Sheets _____ Appendix A

S4516 Serial Communications Board _____ A1

S4563 16 Point 10-30VDC Input (sourcing) _____ A7

S4568 8-Input/8-Output 10-30VDC I/O (sourcing) _____ A11

S4573 16 Point 10-30VDC Output (sourcing) _____ A17

RS-232 Pinouts/Cables _____ Appendix B

Field Wiring Connector Pinouts _____ Appendix C

SECTION 1

GENERAL DESCRIPTION

The M4500 Product Line (generically referred to as the M4500) is a modular design consisting of a series of high performance PLC (Programmable Logic Controller) chassis with a fully integrated PLS (Programmable Limit Switch), digital I/O boards, serial communication board, display/keypads, and power supply. Eight versions are available:

M4500:	4 I/O SLOT PLC/PLS
M4501:	4 I/O SLOT PLC ONLY
M4502:	3 I/O SLOT PLC ONLY WITH DISPLAY/KEYPAD
M4503:	3 I/O SLOT PLC/PLS WITH DISPLAY/KEYPAD
M4508:	8 I/O SLOT PLC/PLS
M4509:	8 I/O SLOT PLC ONLY
M4512:	12 I/O SLOT PLC/PLS
M4513:	12 I/O SLOT PLC ONLY

The M450X part numbers consist of the chassis with processor, resolver interface (M4500, M4503, M4512 and M4508) and either 3 I/O slots (M4502 and M4503), 4 I/O slots (M4500 and M4501), 8 I/O slots (M4508 and M4509) or 12 I/O slots (M4512 and M4513). I/O boards (16 and 32 point Input and 16 point Output) are installed by the user in the I/O slots based on the requirements of the application. The optional D4590 2 Line X 20 character or D4591 2 Line X 40 character displays with 24 key (3 Row X 8 Column) keypads are available for use as a general operator interface or for PLS timing channel programming (the D4591 Display/Keypad is built into the M4502 and M4503). The Serial Communication board is available for communications with other S3000/M4000 products or with other manufactures PLC or host computers.

A typical M4500 system consists of the PLC Processor/Chassis (M4500-M4509), Power Supply (P4500), digital I/O boards (S45XX) as required, Serial Communications boards (S4516) as required, and optional Display/Keypad (D4590 or D4591). The M4502 and M4503 contain a built-in power supply and the D4591 Display/Keypad.

1.1 PLC SECTION

The PLC section of the M4500 is a high performance programmable logic controller which incorporates a built-in processor, user program memory, user data memory, RS-232 programming port, interface to the Display/Keypad, and interface to the I/O slots motherboard. The scan time of the PLC section is on the order of 0.25 milliseconds per K with scan times as low as 80 microseconds for short programs. Two additional interrupt inputs allow through-puts even less than 80 microseconds. Program memory consists of 32K bytes of battery-backed CMOS RAM memory. Data memory consists of 8K bytes RAM memory.

SECTION 1

GENERAL DESCRIPTION

The PLC section supports addressing of up to 12 I/O slots.

Note: Geographical addressing is not used. The slot addresses are specified by dip switches on the I/O board themselves. The PLC section is capable of addressing up to 64 bytes at each slot. Memory mapped I/O is incorporated to provide the greatest degree of flexibility in accessing the I/O boards.

Programming of the PLC section is implemented with SYSdev, an IBM PC or compatible software package that allows the user to create, document, and compile the user logic program as well as directly interface to the M4500 for program down-load and on-line monitoring. Complete program printouts including the user program listing, cross reference, and memory map can also be generated.

1.2 PLS SECTION

The PLS section is a high speed programmable limit or cam switch which accepts angular position information in the form of resolver format signals and converts these to digital. The M4500 is configurable for 8, 16, 32 or 64 timing channels. These are mapped to internal memory locations of the M4500 for use by the PLC section or can be written to output boards for use in general PLS applications. The timing channels can be programmed "on" and "off" at user defined position set-points. Each timing channel can be programmed with up to 50 unique "on-off" set-points or with a pulse train of fixed "on" and "off" divisions throughout the entire channel.

The scale factor of the PLS is programmable from 2 to 4096 divisions per revolution while the offset is programmable from 0 to one minus the scale factor. The PLS supports up to 8 PLS programs when 8 timing channels are used and the scale factor is less than 512 (less PLS programs when more channels are used or the scale factor is greater than 512). A typical application of using multiple PLS programs would be in stamping press applications where different die sets would be used for different stampings. The timing signals for each die set (up to 8 different die sets) would be programmed and saved in a specific PLS program and then as the different die sets were used, the specific PLS program would be called up and used for that die set, saving the operator from having to re-program all the timing signals every time that die set was used.

Speed Compensation is available for timing channels 0 through 7. This is used to compensate for the mechanical response time of a device activated by a particular timing channel. The speed compensation algorithm "leads" the desired activation position by a time in milliseconds entered for that channel. Thus as the speed increases, the point at which the device is activated is advanced to compensate for the response time of the device.

Note: The compensation parameter is entered in milliseconds, not degrees per RPM, which simplifies set-up since the time that is to be compensated for is in milliseconds.

SECTION 1

GENERAL DESCRIPTION

The M4500 is generally interfaced with the RSV34-MS1 resolver as the position transducer, however, virtually any type of resolver which incorporates a rotor reference signal and two stator feedback signals can be used.

1.3 INTERRUPT INPUTS

The M4500 modules contain two 10-30VDC differential interrupt inputs. The inputs are 10-30VDC differential inputs which can be enabled as interrupt inputs or disabled and used as standard inputs. When enabled as interrupts, an "off" to "on" transition of the enabled input activates an interrupt call to a user programmed file (ufunc00 for input0 and ufunc01 for input1). This suspends the main program file until the interrupt file execution is completed, at which time program execution resumes at the place in the main file where the interrupt occurs. This mechanism allows ultra fast through-puts to be implemented if required.

The interrupt inputs are true differential inputs which can be wired as either sinking (true low) or sourcing (true high) depending on the device used to drive the input. Individual LED status indication is provided for each input.

1.4 ANALOG I/O

Two analog inputs and two analog outputs are built into the M4500. The analog inputs are 0-5 volt which can also be used as 0-20ma and 0-10 volt inputs when external resistors are installed to perform the respective conversion (250ohm for 0-20ma, two resistors as a voltage divider for 0-10VDC). The analog outputs are 0-10 volt which can also be used to drive 0-5 volt inputs using a similar external resistor conversion.

The analog inputs are of 10 bit resolution (0-1023) incorporating high speed conversion (less than 25 microsecond) and are updated once every other main scan. The analog outputs are of 8 bit resolution (0-255) and are updated every main scan.

SECTION 1

GENERAL DESCRIPTION

1.5 DISPLAY/KEYPAD

Two Display/Keypads are available for the M4500: the D4590 which incorporates a 2 line X 20 character display and the D4591 which incorporates a 2 line X 40 character display. Both displays incorporate a 24 key keypad which is arranged in 3 rows by 8 columns. Back-lighted LCD technology at 0.19" character height provides both high visibility in low light conditions and high character density.

To minimize space utilization, the keypad/display can be mounted to the back of the M4500 in cases where the M4500 would be door mounted. The D4590 is designed to mount to the back of the M4500/M4501 while the D4591 is designed to mount to the back of the M4508/M4509.

Note: If the display is not mounted to the back of the module, either display can be used with either module. The Display is equipped with a gasket and is fully sealed to prevent the ingress of contaminants to the display or M4500.

The displays can be used as a general purpose operator interface or can be used to implement the PLS programming commands. When used as a general purpose interface, complete control of the display is provided through commands accessed through the user program in the PLC section. Commands such as: "position cursor", "clear display", "enter characters into display", "blink character", as well as an ASCII string conversion system function allow easy and complete control of the display directly in the M4500 user's program. The PLS program commands are resident in the firmware of the M4500 and can either be enabled or disabled in the user's program.

The keypads are 3 row by 8 column sealed keypads which can either be used as a general purpose operator interface or to implement the PLS programming commands. Key depressed decode is performed automatically by the M4500 with the key number depressed mapped directly to an internal memory location of the M4500. The keypad overlay itself simply contains clear windows over the keys. Customization of the keypad is performed by placing a placard behind the overlay (between the overlay and the keys) with the desired key legends. The keys on the D4590 display/keypad are spaced at 0.5" while the keys on the D4591 are spaced at 0.75" spacing.

The D4591 Display/Keypad is built directly into the M4502 and M4503 modules.

1.6 SERIAL COMMUNICATIONS BOARD

Serial communications to other equipment is implemented with the S4516 Serial Communications board. The S4516 contains one S3000 serial network interface port and one RS-232/RS-422 User port. Multiple S4516 boards can be installed in one M4500 (up to the number of slots for that particular model) to allow the use of multiple S3000 network ports or RS-232/RS-422 User ports.

SERIAL NETWORK PORT: The serial network port conforms to the S3000-N1 network protocol. This network is a high speed (up to 344KBPS), twisted pair, serial network configured in a master/slave topology. Up to 32 M4500, S3000, or M4000 modules/processors (nodes) can be connected on one network. Communications between the nodes on the network is controlled via commands (sfunc13) in the user application program resident in the node acting as the master.

USER PORT: This port is available as a general purpose RS-232/RS-422 port accessed under software control of the user program. Typical uses of this port are connection to other control equipment, data acquisition to a host PLC, etc.. Drivers are available for this port that implement the MODBUS protocol and the Allen-Bradley DF1 protocol.

1.7 DIGITAL I/O BOARDS

Digital I/O boards are added to the M4500 by the user as required by the application. All I/O boards incorporate removable field wiring arms for ease of replacement. I/O slot addressing is implemented via dip switches on the I/O boards. Any mix of I/O boards can be installed in an M4500 (all input boards, all output boards, inputs and outputs, etc.).

1.8 DIAGNOSTICS/FAULT DETECTION

The M4500 contains comprehensive fault detection routines which verify the proper operation of the module at all times. Each detected fault has a corresponding fault code which can be viewed using SYSdev, providing a description of the fault and recommended corrective action. In addition, the M4500 contains a fault interlock output (24VDC, 500mAMP, sinking) which can be interlocked to the control system for system shut down or annunciation when a fault is detected. In addition to the fault detection, a hardware confidence test is resident in the module to provide a complete test of the internal module hardware. This test is initiated through SYSdev and can be used to verify the M4500 for proper operation.

SECTION 1

GENERAL DESCRIPTION

1.9 LED STATUS INDICATIONS

The following three status LED's are located on the front M4500: PWR, RUN, and FLT. The definitions of these LED's are as follows:

PWR: "On" when +5VDC power is applied to the M4500.


RUN: "On" steady when the M4500 is running a valid user's application program. "Off" when an internal fault is detected or when a valid user's program has not been loaded. The RUN led is flashed during program download and also when the hardware confidence test is executed.

FLT: "On" when an internally detected fault has occurred in the M4500. See section 6 for more details on the fault routines and error codes.

2.1 PLC PROGRAM STRUCTURE

The PLC section of the M4500 is programmed with SYSdev. The SYSdev programming language is a combination of Ladder, High-level (subset of C) and Assembly (MCS-96). All the files which comprise a SYSdev program are programmed in the same language format. Each file can be written in any combination of the language types. The typical M4500 PLC program consists of the following files:

- 1) Initialization file (optional): executed once at power up.
- 2) Main Program file (required): scanned continuously.
- 3) Timed Interrupt file (optional): executed once every 0.250 to 65.000 milliseconds as set by the user.
- 4) User Function file (optional): up to 100 user defined subroutines which can be called from any of the above files.
- 5) Input Interrupts (optional): the two input interrupts can be enabled or disabled independently. When the interrupts are enabled, Input0 interrupt calls ufunc00 when activated ("off" to "on" transition of input0) while input1 interrupt calls ufunc01.



Note: ufunc00 must be created by the user if the input0 interrupt is enabled and ufunc01 if the input1 interrupt is enabled.

Each file is executed sequentially from beginning to end. The main program file is executed (scanned) continuously unless interrupted by the timed interrupt or either of the input interrupts. When this occurs, main program execution is suspended while the interrupt file is executed. At the completion of the interrupt, program execution resumes at the point in the main program where the interrupt occurred.

Each file is implemented as a series of consecutive blocks. Each block is defined as one of the three programming languages: Ladder, High-level or Assembly. Blocks of the different languages can be intermixed as necessary within the file.

Since the M4500 incorporates memory mapped I/O, I/O update is performed by the user's application program. In most applications this is done at the beginning of the main program and/or the beginning of the timed interrupt.

See the M4500 Program Development Manual for complete details on programming the PLC section of the M4500.

SECTION 2

PLC FEATURES

2.2 SPECIAL FUNCTION VARIABLES (SFV's) (Directly addressed)

Many of the features of the M4500 are accessed via certain variables in the M4500. These are referred to as "Special Function Variables". The following is the list of SFV's of the M4500 and is provided as a reference only. For a complete description of each SFV, refer to the M4500 Program Development Manual.

<u>Address</u>	<u>Description</u>
B160	PLS Command Flags:
B160.0	Execute PLS command (from PLC)
B160.1	Reserved (Do not access)
thru	
B160.5	Reserved (Do not access)
B160.6	Bypass "Recall" Ack
B160.7	Reserved (Do not access)
B161	System Enable Flags:
B161.0	PLS Mode Enable
B161.1	PLS CH0-7 Speed Compensation Enable
B161.2	PLS Keypad Commands Enable
B161.3	Analog I/O Update Enable
B161.4	PLS Update in TIMED(1)/ PLS Update in MAIN(0)
B161.5	PLS Program Commands Enable
B161.6	sfunc13 slave mode enable in S4516
B161.7	sfunc18 interleaved(0)/ executed complete(1)
W162	AIN0 - Analog Input 0 (0-1023)
W164	AIN1 - Analog Input 1 (0-1023)
B166	AOUT0 - Analog Output 0 (0-255)
B167	AOUT1 - Analog Output 1 (0-255)
B170	CH0 PLS Channel byte 0 (CH00-07)
B171	CH1 PLS Channel byte 1 (CH10-17)
B172	CH2 PLS Channel byte 2 (CH20-27)
B173	CH3 PLS Channel byte 3 (CH30-37)
B174	CH4 PLS Channel byte 4 (CH40-47)
B175	CH5 PLS Channel byte 5 (CH50-57)
B176	CH6 PLS Channel byte 6 (CH60-67)
B177	CH7 PLS Channel byte 7 (CH70-77)

SECTION 2 PLC FEATURES

<u>Address</u>	<u>Description</u>
W178	Resolver Position (updated in TIMED Interrupt)
W180	Resolver Position (updated in MAIN Program)
W182	Resolver RPM
W184	Resolver Period (msec per revolution)
W186	Resolver Scale Factor
W188	Resolver Offset
W192	Resolver Period (speed compensation)
B191	Depressed Key on Keypad (0=no key, 1-24=key)
B194	Display wait delay (B194=28 for D4590, B194=47 for D4591)
B8158	Keypad Debounce time (in main scans)
W8154	Slave Slot Address for S4516 sfunc13 slave mode
W8156	S4516 Slot Address for sfunc10/11/13
B8159	Current Firmware Revision

PLS Programming (from PLC) SFV's:

B190	Selected PLS Channel Program (0-7)
B212	PLS Command:
	B212=09: Recall Channel
	B212=27: Single set-point programming command
	B212=43: Pulse Train Programming command

For Recall Channel command:

B213	Channel to read (set by user prior to command)
B213	Recall State (0="off", 1="on") (return value)
W214	Position of set-point change of state (return value)

For Single set-point command:

B213	Channel to program set-point
W214	"ON" setpoint (in degrees)
W216	"OFF" setpoint (in degrees)
B218	Program state (0="off", 1="on")

For Pulse Train command:

B213	Channel to program set-point
W214	"START" position (in degrees)
B216	"ON" Duration
B217	"OFF" Duration

SECTION 2

PLC FEATURES

2.3 SPECIAL FUNCTION VARIABLES (SFV's) (Indirectly addressed)

<u>Address</u>	<u>Description</u>
2100H	Number of PLS Channels (8,16,32,64)
2126H	CH0 Speed Compensation (active)
2127H	CH1 Speed Compensation (active)
2128H	CH2 Speed Compensation (active)
2129H	CH3 Speed Compensation (active)
212aH	CH4 Speed Compensation (active)
212bH	CH5 Speed Compensation (active)
212cH	CH6 Speed Compensation (active)
212dH	CH7 Speed Compensation (active)
2200H-2207H	Speed Compensation array (PLS program=0)
2208H-220fH	Speed Compensation array (PLS program=1)
2210H-2217H	Speed Compensation array (PLS program=2)
2218H-221fH	Speed Compensation array (PLS program=3)
2220H-2227H	Speed Compensation array (PLS program=4)
2228H-222fH	Speed Compensation array (PLS program=5)
2230H-2237H	Speed Compensation array (PLS program=6)
2238H-223fH	Speed Compensation array (PLS program=7)

2.4 MEMORY MAPPED I/O

X and Y variables are not supported in the M4500. Instead the I/O slots of the chassis are mapped into the memory space of the M4500, accessed as Byte(B) variables. The addresses of the different slots are assigned as follows:

<u>Group-Slot</u>	<u>Byte</u>	<u>Address</u>
0-0	0	B7424
	1	B7425
	2	B7426
	3	B7427
0-1	0	B7488
	1	B7489
	2	B7490
	3	B7491
0-2	0	B7552
	1	B7553
	2	B7554
	3	B7555
0-3	0	B7616
	1	B7617
	2	B7618
	3	B7619
1-0	0	B7680
	1	B7681
	2	B7682
	3	B7683
1-1	0	B7744
	1	B7745
	2	B7746
	3	B7747
1-2	0	B7808
	1	B7809
	2	B7810
	3	B7811
1-3	0	B7872
	1	B7873
	2	B7874
	3	B7875

SECTION 2

PLC FEATURES

Unlike the S3000 and M4000, the M4500 does not automatically perform the I/O update at the beginning of the program. The I/O update on the M4500 is performed by the user's program. Internal Byte(B) variables serve as the I/O image. Input boards are read and stored in the input image (B) bytes while output image (B) bytes are used to store the value of the outputs and then are written to the outputs. See the M4500 Program Development Manual for more details.

3.1 STANDARD PLS FEATURES

The following are the standard PLS features built into the M4500 firmware. These features are available independent of the user's PLC application program.

3.1.1 TIMING CHANNELS

The M4500 is configurable for 8, 16, 32 or 64 timing channels. These are mapped to internal memory locations of the M4500 for use by the PLC section or can be written to output boards for use in general PLS applications. The timing channels can be programmed "on" and "off" at user defined position set-points. Each timing channel can be programmed with up to 50 unique "on-off" set-points or with a pulse train of fixed "on" and "off" divisions throughout the entire channel.

The number of timing channels used (8, 16, 32, or 64) is predicated by the application. On applications requiring a large number of channels, up to 64 are available. On applications requiring only a small number of channels, as few as 8 are available. The more channels used, the higher the over-head scan time will be to implement the timing channels. Therefore, it is advantageous to configure the M4500 for no more than the number of channels that are required.

3.1.2 SCALE FACTOR

The scale factor of the PLS is programmable from 2 to 4096 divisions per revolution. If 360 degrees are to be used, set the scale factor to 360.

3.1.3 OFFSET (ELECTRONIC ZERO)

The offset is used to electronically zero the resolver shaft. The M4500 contains an auto zero algorithm which will automatically calculate the offset required to make the current position of the resolver shaft zero. This is implemented by simply entering "0" for the offset. This indicates to the M4500 to auto zero the offset. In addition, the user can actual enter the desired position that is to be zero. This allows the offset to be set in any way desired.

SECTION 3

PLS FEATURES

3.1.4 PLS PROGRAMS

The PLS supports up to 8 PLS programs. A typical application of using multiple PLS programs would be in stamping press applications where different die sets would be used for different stampings. The timing signals for each die set (up to 8 different die sets) would be programmed and saved in a specific PLS program and then as the different die sets were used, the specific PLS program would be called up and used for that die set, saving the operator from having to re-program all the timing signals every time that die set was used.

The number of PLS programs which can be used is a function of the number of channels used and the scale factor used. The matrix below outlines how many PLS programs are available as a function of the scale factor and number of channels. The numbers in the matrix are the number of PLS programs available. An "*" indicates an invalid scale factor/number of channels combination.

Scale Factor	Number of Channels			
	8	16	32	64
0 - 511	8	4	2	1
512 - 1023	4	2	1	*
1024 - 2047	2	1	*	*
2048 - 4096	1	*	*	*

3.1.5 SPEED COMPENSATION

Speed Compensation is available for timing channels 0 through 7. This is used to compensate for the mechanical response time of a device activated by a particular timing channel. The speed compensation algorithm causes the timing channel to "lead" the programmed timing set-point for that channel by a time in milliseconds entered for that channel. Thus as the speed increases, the point at which the device is activated is advanced to compensate for the response time of the device.

Note: The compensation parameter is entered in milliseconds, not degrees per RPM, which simplifies set-up since the time that is to be compensated for is in milliseconds.

The speed compensation feature is enabled with bit 1 in the System Enable Byte (B161). When enabled, the speed compensation for channels 00 through 07 can all be set independently to any value between 0 and 255 milliseconds. If speed compensation for a particular channel is not to be used, set the compensation value to "0".

3.2 ADVANCED PLS FEATURES

The PLS is fully integrated with the PLC. What this means is that the actual resolver position, current RPM, and every other PLS parameter can be accessed by the PLC section. The PLC can even execute the PLS programming commands that would normally be executed through SYSdev or the D4590/91 Display/Keypad. This allows virtually any PLS feature that can be dreamed of to be implemented. Examples of this are:

Brake Wear Compensation: The brake wear compensation algorithm is used in conjunction with presses which incorporate a top dead center (TDC) or back dead center (BDC) stop. With these presses, a timing signal is used to de-clutch the press for TDC or BDC stops. However, as the brake wears, the press will no longer stop at TDC but will instead overshoot. The brake wear compensation algorithm automatically adjusts the TDC timing such that the press always stops at the desired stopping position regardless of brake wear.

Brake Wear Alarm: In conjunction with the brake wear compensation, brake response determination and a brake wear alarm can be implemented in the PLC section. This determines the actual number of degrees the brake takes to stop the press (from de-clutch to stop). The brake wear alarm can be activated if the brake response exceeds a preset number of degrees.

Speed Windows: These signals can be activated at preset speed thresholds as desired or needed. Since the RPM is directly available to the PLC section, virtually an unlimited number of speed windows could be generated by the PLC section.

Automatic Zero: Since the offset of the PLS can be accessed by the PLC section, it can also be changed in response to any desired logic condition, even as a function of speed which would, in affect, implement a speed compensation for all the timing channels.

The above advanced PLS features are not implemented in the firmware of the M4500 but would be instead implemented with user logic in the PLC section of the M4500.

SECTION 3

PLS FEATURES

3.3 PLS CHANNEL PROGRAMMING

The PLS section of the M4500 is programmed either through SYSdev using an IBM PC or Compatible or through the PLS commands of the D4590 or D4591 Display/Keypad. When using SYSdev, the PLS section can either be configured and the timing signals programmed off-line and then down-loaded to the M4500 or the PLS timing channels can be programmed on-line, while the M4500 is in operation. The IBM PC or compatible is interfaced to the PLS section of the M4500 via the "PROG" port of the M4500 using an RS-232 cable from the COM port on the computer. The following PLS programming commands are available when using SYSdev or the D4590/91 Display/Keypad:

PLS Configuration including:

- Scale Factor (2-4096)
- Offset
- Selected PLS Program (0-7)
- Number of Timing Channels (8,16,32,or 64)
- Timing Channel Speed Compensation (Channels 00 thru 07)

On and Off-line timing channel programming including:

- single set-point programming
- pulse train channel programming
- timing channel fine tune (SYSdev only)

Channel set-points download to M4500 (SYSdev only)

Channel set-points upload from M4500 (SYSdev only)

Configuration and channel set-points print-outs (SYSdev only)

See section 4 for details on programming the PLS section using the keypad/display. See section 5 for details on programming the PLS section using SYSdev.

3.4 IMPLEMENTING M4500 AS A STAND-ALONE PLS

The M4500 is fundamentally a PLC with built-in PLS features. The M4500 can be used as a stand-alone PLS (PLC section not used) by downloading the program "BASICPLS" to the M4500. This is a PLC program which simply enables all the PLS features and maps the timing channels to the following outputs:

CH00-07	OUTPUT SLOT0-0: BYTE0
CH10-17	OUTPUT SLOT0-0: BYTE1
CH20-27	OUTPUT SLOT0-1: BYTE0
CH30-37	OUTPUT SLOT0-1: BYTE1
CH40-47	OUTPUT SLOT0-2: BYTE0
CH50-57	OUTPUT SLOT0-2: BYTE1
CH60-67	OUTPUT SLOT0-3: BYTE0
CH70-77	OUTPUT SLOT0-3: BYTE1

The "BASICPLS" program is included with the SYSdev software package and is loaded into the "EXAMPLES" sub-directory of the "PLS51" sub-directory. To download "BASICPLS" into the M4500, perform the following:

- 1) Power up the M4500 and the IBM PC or compatible loaded with SYSdev.
- 2) Connect an RS-232 cable from the computer COM port to the "PROG" port on the M4500.
- 3) From the root directory of the hard drive that SYSdev is loaded on, type:
SYSDEV \PLS51\EXAMPLES BASICPLS<ENTER>.
- 4) From the main development menu of SYSdev, select "6: Target Board Interface".
- 5) Download the "BASICPLS" application program to the M4500 by selecting "1: Download Program to Target Board" from the target board interface menu. A prompt will be displayed verifying the download, press the <ENTER> key to start the download. Once the download is complete, press any key to return to the target board interface menu.
- 6) Return to the SYSdev main menu and then exit SYSdev.

When loaded with "BASICPLS", the M4500 will simply perform as a programmable limit switch. The timing channels can be programmed with either SYSdev or through the keypad of the D4590/91. All PLS features are enabled including speed compensation, etc.

SECTION 3

PLS FEATURES

(This Page Intentionally Left Blank)

SECTION 4

PLS PROGRAMMING

USING THE KEYPAD/DISPLAY

The D4590 and D4591 are keypad/displays that can be used as general purpose operator interfaces as well as PLS programmers for the M4500. The PLS programming commands and menu displays are built-in into the firmware of the M4500 and active when the display is not used as a general purpose operator interface. When used as a PLS programmer, the keypad/displays are used to configure and program the timing channels of the M4500. The keypad/displays incorporate a built in 2 line by 20 or 40 character alphanumeric display which displays command prompts, set-point data, configuration data, as well as the resolver position or speed (RPM) in real-time. Of the 24 keys of the keypad, 18 of the keys are used to select the PLS programming commands and enter data.

4.1 CHANNEL SET-POINT PROGRAMMING COMMANDS

Three channel set-point programming commands are available with the keypad/displays: single set-point programming, pulse train programming, and clear channel. The single set-point command is used to enter a unique "on" set-point in a channel. This command programs the channel "on" from a user specified "on" position to a user specified "off" position. The pulse train command is used to program a channel with set-points of a fixed "on" and "off" duration through-out the entire channel. The clear channel command is used to clear all set-points from the currently selected channel.

4.2 PLS CONFIGURATION PARAMETERS

In addition to channel programming, the keypad/displays are used to set the M4500 PLS configuration. This includes setting the PLS scale factor and offset, select the PLS program, and set the speed compensation for channels 00 through 07.

SECTION 4

PLS PROGRAMMING

USING THE KEYPAD/DISPLAY

4.3 PLS KEY DEFINITIONS

The keypad/displays contain a 24 key keypad with 10 numerical keys and 6 command keys. The command keys are defined as follows:

[SET POINT]	Used to enter single set-points in the currently selected channel. See section 4.7.
[PULSE TRAIN]	Used to program a channel with set-points of a fixed "on" and "off" duration through-out the entire channel. See section 4.8.
[CLEAR CHAN]	Used to clear all set-points from the currently selected channel.
[CONFIG]	Used to set the PLS configuration parameters including: the scale factor, offset, select the PLS program, and set the speed compensation for channels 00 through 07. See section 4.5.
[SELECT CHAN]	Used to select the desired channel, either to program or to search. See section 4.6.
[SEARCH]	Used to search and display the set-point "on" and "off" transitions in the currently selected channel. See section 4.10.
[ESC]	Used to cancel the current command in progress

The keys are mapped to the keypad as shown in figure 4.1 below:

F1	F4	SET- POINT	CLEAR CHAN	1	2	3	ENTER
F2	F5	PULSE TRAIN	SELECT CHAN	4	5	6	ESC
F3	F6	CONFIG	SEARCH	7	8	9	0

Figure 4.1 - PLS Keypad Assignments

SECTION 4

PLS PROGRAMMING USING THE KEYPAD/DISPLAY

4.4 PLS DISPLAY FIELDS

The keypad/displays contain either a 2 line by 20 character (D4590) or 2 line by 40 character back-lighted LCD display which normally displays a default channel message or various prompts while commands are entered. The format of the default channel message is:

```
CH:xx SETPT:yyy [ ]  
RPM:0000 POS:888
```

- 1) "**xx**" is the currently selected channel in octal .
- 2) "**yyy**" is the position where the set-point transition is located.
- 3) The [] after the set-point position is the channel status indicator.
 - a) If the channel status indicator is a solid block "[]", the set-point transitions "on" at the displayed position.
 - b) If the channel status indicator is blank, the set-point transitions "off" at the displayed position.
 - c) If the channel is programmed either all "on" or all "off", the position will read "---" and the channel state indicator will be set "on" or "off" as appropriate.

4.5 SETTING THE PLS CONFIGURATION

The following PLS configuration parameters can be set via the keypad/display [CONFIG] command: PLS program, scale factor, offset, and CH00 through CH07 speed compensation.

Note: Once the [CONFIG] command is initiated, each parameter will be prompted for and displayed sequentially by the keypad/display. To simply view the existing configuration parameters without changing them, press [ENTER] when the corresponding parameter is displayed. The [CONFIG] command can be exited at any time simply by pressing the [ESC] key.

The following configuration parameters are prompted for sequentially:

- 1) PLS Program (0-7)
- 2) Offset (0 to Scale Factor-1)
- 3) Scale Factor (2-4096)
- 4) Number of Timing Channels (8,16,32,or 64)
- 5) CH00 Speed Compensation (0 to 255msec)
- 6) CH01 Speed Compensation (0 to 255msec)
- 7) CH02 Speed Compensation (0 to 255msec)
- 8) CH03 Speed Compensation (0 to 255msec)
- 9) CH04 Speed Compensation (0 to 255msec)
- 10) CH05 Speed Compensation (0 to 255msec)
- 11) CH06 Speed Compensation (0 to 255msec)
- 12) CH07 Speed Compensation (0 to 255msec)

SECTION 4

PLS PROGRAMMING

USING THE KEYPAD/DISPLAY

To view or set the configuration parameters, perform the following:

- 1) Press the [CONFIG] key to initiate the configuration command.
- 2) The display will now read "PLS PROGRAM:x" where x is the currently selected PLS program. To select a new PLS program, enter a number between 0 and 7 and press [ENTER]. The timing set-points for the selected PLS program will be recalled from memory and used as the active set-points for the timing signals. If the PLS program is not to be changed, simply press [ENTER].
- 3) Now the display will read "OFFSET:xxxx" where xxxx is current offset. This offset is used primarily to electronically zero the resolver shaft at machine zero. The offset can be programmed from 0 to one minus the scale factor. To set the offset, perform the following: Locate the machine at machine zero. Read the resolver shaft position on the keypad/display. Enter the value read and press [ENTER]. The M4500 will calculate the value required to make the position entered machine zero and enter this as the offset (this value may not equal the value entered).

Alternatively, the resolver can be zeroed simply enter the number 0 and pressing [ENTER]. The M4500 PLS contains an auto zero algorithm which will calculate the offset required to make the current position zero.

To continue without changing the offset, simply press [ENTER].

- 4) Next the display will read "SCALE FACTOR:xxxx" where xxxx is the current scale factor. The scale factor of the M4500 PLS is programmable from 2 to 4096 divisions per revolution. For 360 degrees per revolution, the scale factor should be set to 360. To change the scale factor, enter the new scale factor and press [ENTER]. To continue without changing the scale factor simply press [ENTER].

CAUTION!!

Changing the scale factor after timing channels have been previously programmed will result in invalid set-points. It is recommended that all timing channels be re-programmed after setting the scale factor.

- 5) The display will now read "NUMBER CHANNELS:xx" where xx is the currently specified number of channels. The M4500 PLS supports either 8, 16, 32 or 64 timing channels. Enter the number of channels to be used (8, 16, 32, or 64) and press [ENTER]. If the number of channels are not to be changed, simply press [ENTER] to continue.
- 6) The last set of configuration parameters that will be prompted for are the speed compensation presets for channels 00 through 07. Each of these channels can be programmed to have from 0 to 255 milliseconds of timing signal "lead" (see section 3.1.5). The values entered for the speed compensation are in milliseconds. This is the amount of time that the timing signal will lead the programmed timing set-point as the speed of the machine is varied. The speed compensation for each channel is independently set.

The display will prompt "CHxx SPEED COMP:yyy" where xx is the channel (00 to 07) and yyy is the currently programmed speed compensation (in milliseconds) for that channel. To change the compensation value, enter the new number (from 0 to 255) and press [ENTER]. The compensation for the next channel will then displayed. If speed compensation for a particular channel is not to be used, enter "0" for the compensation for that channel. If the compensation value for a particular channel is not to be changed, simply press [ENTER] to continue.

SECTION 4

PLS PROGRAMMING USING THE KEYPAD/DISPLAY

- 7) The [CONFIG] command is now complete, the display will return to showing the last channel and set-point selected.

4.6 SELECTING A NEW CHANNEL NUMBER

To select a new channel number, either to search for set-points or to program, perform the following:

- 1) Press the [SELECT CHAN] key.
- 2) The display will prompt "ENTER CHAN: _". Enter the new channel, in octal, and press the [ENTER] key.

Note: Valid channel numbers are 00 thru 07, 10 thru 17, 20 thru 27, 30 thru 37, etc..

Example #1: The following example sets the working channel to 01:

<u>Key Depressed</u>	<u>Display</u>
[SELECT CHAN]	ENTER CHAN: _
[1]	ENTER CHAN: 1 _
[ENTER]	CH:01 SETPT:xxx []

4.7 SINGLE [SET-POINT] PROGRAMMING COMMAND

The single set-point command is used to enter a unique "on" set-point in the currently selected channel. This command programs the channel "on" from a user specified "on" position to a user specified "off" position.

Note: Programming a new set-point in a channel does not clear out any previous set-points. This allows multiple set-points to be programmed in a channel. If a channel is to be "moved", the channel must first be cleared and then re-programmed using the [SET-POINT] command.

To program a single set-point, perform the following:

- 1) Press the [SET-POINT] key to initiate the single set-point programming command.
- 2) The display will prompt ""ON" SETPT: _". Enter the position the set-point is to turn "on" and press [ENTER].
- 3) The display will now prompt ""OFF" SETPT: _". Enter the position the set-point is to turn "off" and press [ENTER].
- 4) The M4500 PLS will now program the channel "on" from the entered "on" position to the entered "off" position.

Note: Any number of unique set-points may be entered in a selected channel. In addition, the entire channel can be programmed "on" simply by specifying the "on" and "off" prompts with the same position.

SECTION 4

PLS PROGRAMMING

USING THE KEYPAD/DISPLAY

Example #1: The following key sequence programs the currently selected channel "on" from 20 degrees to 40 degrees:

<u>Key Depressed</u>	<u>Display</u>
[SET-POINT]	"ON" SETPT:_ []
[2]	"ON" SETPT:2_ []
[0]	"ON" SETPT:20_ []
[ENTER]	"OFF" SETPT:_
[4]	"OFF" SETPT:4_
[0]	"OFF" SETPT:40_
[ENTER]	CH:xx SETPT:020 []

Example #2: This example programs the selected channel entirely "on" by entering 000 for both the "on" and "off" prompts:

<u>Key Depressed</u>	<u>Display</u>
[SET-POINT]	"ON" SETPT:_ []
[0]	"ON" SETPT:0_ []
[ENTER]	"OFF" SETPT:_
[0]"	OFF" SETPT:0_
[ENTER]	CH:xx SETPT:--- []

4.8 [PULSE TRAIN] PROGRAMMING COMMAND

The pulse train command is used to program a channel with set-points of a fixed "on" and "off" duration through-out the entire channel in one simple command. To program a channel with a pulse train perform the following:

- 1) Press the [PULSE TRAIN] key to initiate the pulse train programming command.
- 2) The display will prompt ""ON" DUR:_ ". Enter the desired "on" duration in degrees and press [ENTER].
- 3) The display will now prompt ""OFF" DUR:_ ". Enter the desired "off" duration in degrees and press [ENTER].
- 4) The display will now prompt ""START" POS:_ ". Enter the location, in degrees, were the first "on" set-point will start and press [ENTER].
- 5) The entire channel will now be programmed with the "on" and "off" duration through-out the channel starting at the specified "start" location.

SECTION 4

PLS PROGRAMMING

USING THE KEYPAD/DISPLAY

Example #1: The following key sequence programs the selected channel as a pulse train with multiple set-points of an "on" duration of 2 degrees and an "off" duration of 4 degrees starting at position 001:

<u>Key Depressed</u>	<u>Display</u>
[PULSE TRAIN]	"ON" DUR:_ []
[2]	"ON" DUR:2_ []
[ENTER]	"OFF" DUR:_
[4]	"OFF" DUR:4_
[ENTER]	"START" POS:_
[1]	"START" POS:1_
[ENTER]	CH:xx SETPT:001 []

4.9 [CLEAR CHANNEL] COMMAND

The clear channel command is used to clear all the set-points in the currently selected channel. To clear the channel, perform the following:

- 1) Press the [CLEAR CHAN] key to clear the channel.
- 2) The display will display "CH:xx SETPT:---" indicating that the channel has been cleared.

4.10 SEARCHING (RECALLING) A CHANNEL

To view the position and status of set-points in the current channel, perform the following:

- 1) Press the [SEARCH] key. The starting or ending position (transition) of the next set-point is displayed. If the position is the "off" to "on" transition of the set-point, the channel state indicator will be "on". If the position is the "on" to "off" transition, the channel state indicator will be "off".
- 2) Press the [SEARCH] key again to view the next set-point transition. Continuing to depress the [SEARCH] key displays all set-point transitions within the channel.

Example: This example searches a channel programmed with two set-points, one "on" at 20 and "off" at 40, and another "on" at 60 and "off" at 80:

<u>Key Depressed</u>	<u>Display</u>
[SEARCH]	CH:xx SETPT:020 []
[SEARCH]	CH:xx SETPT:040
[SEARCH]	CH:xx SETPT:060 []
[SEARCH]	CH:xx SETPT:080
[SEARCH]	CH:xx SETPT:020 []

SECTION 4

PLS PROGRAMMING

USING THE KEYPAD/DISPLAY

(This Page Intentionally Left Blank)

SECTION 5

PLS PROGRAMMING USING SYSdev

SYSdev is a DOS based software package used for program development (Ladder and High-Level) of the PLC section of the M4500. In addition, SYSdev can be used to configure and program the timing channels of the M4500 PLS. An RS-232 cable connected to the COM port of an IBM PC or compatible running SYSdev is used to interface with the M4500 module for on-line programming, program upload, download, etc. No other additional hardware is required.

5.1 PLS FEATURES OF SYSdev

SYSdev incorporates the following PLS programming features:

- 1) Online Channel Set-point Programming: using the same set-point programming commands and menus used with the off-line channel programming, the user can alter channel set-points in the M4500 module directly using an RS-232 cable which connects the M4500 module to the COM port of an IBM PC or compatible running SYSdev. This allows machine timing to be altered while in operation.
- 2) Offline Channel Set-point Programming: set-points for each channel can be entered with easy to use set-point programming commands and saved on disk for download to the M4500 at a latter time. This allows the channel programming to be implemented without having an M4500 present.
- 3) PLS Configuration: the configuration of the M4500 is set using SYSdev. This includes defining: the PLS program, scale factor, the number of PLS timing channels, and the speed compensation for channels 00 through 07.
- 4) Download Channels to PLS: this allows channels edited in off-line mode or previously uploaded channels to be downloaded to the M4500 module. This feature allows quick replacement of an M4500 module by eliminating the need to reprogram the channel set-points by hand.
- 5) Upload Channels from PLS: uploads channel set-points and configuration parameters from the M4500 module to disk files.
- 6) Print-outs: the set-points of all channels as well as the PLS configuration can be printed out to provide hard copy documentation.

Refer to the SYSdev Programming Manual for details on installing SYSdev on the hard drive of your computer.

SECTION 5

PLS PROGRAMMING

USING SYSdev

5.2 PLS MENUS

The following sections are a description of the various PLS menus of SYSdev. In general, the PgUp, PgDn, Home, End, and cursor left, right, up, and down keys all function as defined.

5.2.1 MAIN DEVELOPMENT MENU

1: Online Channel Setpoint Programming

This selection is used to edit the channel set-points in an M4500 module directly. To initiate the on-line programming mode, connect the COM port on the PC running SYSdev to the "PROG" port on the M4500 to be programmed. Select "1: Online Channel Setpoint Programming". The "channel edit menu" will be invoked and the existing channel set-points in the M4500 will be uploaded and displayed in the menu. See section 5.2.2 for a description of the "channel edit menu" and set-point programming commands.

Note: Any changes to the channel set-points made are updated immediately to the M4500 module. This allows set-point editing during machine operation if desired. When editing is complete, press "ESC" to return to the main development menu. The modified channel set-points will also be saved in the channel data file on disk for the selected program when exiting the on-line mode.

2: Offline Channel Setpoint Programming

This selection is used to edit the channel set-points off-line while not connected to an M4500 module. All changes made to the channel set-points are saved in the channel data file for the selected program. The channel set-points can then be downloaded to an M4500 module using the "Download Channels to PLS" selection. To initiate the off-line programming mode, select "2: Offline Channel Setpoint Programming". This invokes the "channel edit menu" and loads the existing channel set-points from the channel data file on disk. See section 5.2.2 for a description of the "channel edit menu" and set-point programming commands. When editing is complete, press "ESC" to return to the main development menu. The modified channel set-points will then be saved in the channel data file on disk for the selected program.

3: Edit PLS Configuration

This activates the PLS configuration menu (See section 5.3). When SYSdev is initially invoked and the program name entered does not exist, the PLS configuration menu is automatically activated. This selection allows the user to modify the system configuration at any time.

4: Download Channels to PLS

This selection downloads both the PLS configuration and channel data files for the selected program to the M4500 module. To download the data to the M4500, perform the following:

Note: Each channel is cleared prior to downloading the set-points for that channel, thus machine operation should be ceased prior to initiating the download.

- 1) With both the PC running SYSdev and the M4500 powered up, connect the COM port on the PC to the "PROG" port on the M4500 using the appropriate RS-232 cable.
- 2) Select this selection from the main development menu. A prompt will appear to verify whether to continue or not. To abort the download press "ESC", otherwise press any key to start the download.
- 3) While the download is in progress, the channel number which is currently being downloaded will be displayed. Once all channels are downloaded, a dump complete message will be displayed along with a prompt to return to the main menu. Press any key to return to the menu.
- 4) If the computer was unable to initiate the download to the M4500, a message stating this will be displayed. Verify the RS-232 cable connections between the COM port on the computer and the "PROG" port on the M4500. Press any key to return to the main development menu and try the download again.

5: Upload Channels from PLS

This selection uploads the set-points for each channel from the M4500 and saves it in the channel data file of the currently selected program.

Note: The configuration data is also uploaded from the M4500 as well. To upload the data from the M4500, perform the following:

- 1) With both the PC running SYSdev and the M4500 powered up, connect the COM port on the PC to the "PROG" port on the M4500 using the appropriate RS-232 cable.
- 2) Select this selection from the main development menu. A prompt will appear to verify whether to continue or not. To abort the upload press "ESC", otherwise press any key to start the upload.
- 3) While the upload is in progress, the channel number which is currently being uploaded will be displayed. Once all channels are uploaded, an upload complete message will be displayed along with a prompt to return to the main menu. Press any key to return to the menu.
- 4) If the computer was unable to initiate the upload to the M4500, a message stating this will be displayed. Verify the RS-232 cable connections between the COM port on the computer and the "PROG" port on the M4500. Press any key to return to the main development menu and try the upload again.

SECTION 5

PLS PROGRAMMING

USING SYSdev

6:Print Channels

Both the PLS configuration data and channel set-points data can be printed out through SYSdev. When this selection is made, a printer selection menu is displayed. Select the appropriate printer to be used. Once this is done, the print-outs selection menu is displayed. The selections are:

1: Print PLS Channel Set-points

This selection prints the set-points for all the channels. For each channel the following is printed:

CHANNEL: number DESCRIPTION:users documentation

PULSE TRAIN: yes/no ON:--- OFF:--- START:---

SET-POINTS:

	ON	OFF
1:	___	___
	-	___
	etc.	

The above is the set-points data for the respective channel as entered through the "channel edit menu".

2: Print PLS Configuration

This selection prints the configuration parameters as entered in the PLS configuration menu.

3: Enter PLS Program Title

This selection allows the user to enter a title for the program. This title is printed at the top of each page of both the PLS Channel Set-points print-out and the PLS Configuration print-out. The title can be up to 60 characters long and can be composed of any printable characters. When entry of the title is complete, press Enter<CR> to save the title. If the title or changes to the title are not to be saved, press "ESC".

SECTION 5

PLS PROGRAMMING

USING SYSdev

7: File Utilities

The SYSdev program allows you to back-up, restore, make a new directory, and to copy the current PLS program to another PLS program name all while inside SYSdev. Selecting File Utilities brings up a sub-menu with the following choices:

1: Back-up Program

This allows the current program to be backed up on a diskette in drive A:. Install the back-up diskette in drive A: and press any key when ready. This copies all the files associated with the program to the root directory of the A: drive.

Note: The files will be stored at the root directory of the diskette, not within a sub-directory. This selection provides a convenient way to back-up your program.

2: Restore Program

This copies the current program name from the root directory of the A: drive to the drive and directory specified with the current program name. Install the diskette with the program on it in the A: drive and press any key when ready. This copies all the files associated with the program name on the A: drive to the path specified with the program name.

Note: The program files on the diskette in drive A: must be at the root directory. This selection, along with the back-up selection above, provides a convenient way to copy programs from one computer to another.

3: Make new directory

This provides a way to make a new user program directory while inside SYSdev. Enter the drive and directory name following the MS-DOS conventions of directory names.

4: Copy program to another program name

This provides a way to copy the current program name to any disk and directory while also allowing the user to copy to a different program name. Enter the drive, directory, and new program name using the MS-DOS conventions for directory and file names. Do not enter an extension with the program name. This copies all the files associated with the program to the different directory and program name. This selection can be used to copy the current name to another drive and directory (when the program name entered is the same as the current program name). This is also used to copy the program to a new program name. For instance when one program is similar to another completed program, simply copy the old program to the new program name and edit as required.

SECTION 5

PLS PROGRAMMING

USING SYSdev

5.2.2 CHANNEL EDIT MENU

This menu is invoked for both off-line and on-line programming and provides a mechanism to enter and edit the set-points for the channels. The menu contains both information fields and function key commands. The information fields are defined as follows:

- CHANNEL:** This is the number (in octal) of the currently selected and displayed channel. When the channel edit menu is initially invoked, channel number 00 is selected and displayed. The "F1: Next Chan", "F2: Prev Chan", and "F3: Select Chan" commands are used to select a different channel number.
- DESCRIPTION:** This field contains the user entered description or channel name which is associated with the channel number. The "F4: Doc Chan" command is used to enter or edit this description.
- PROG MODE:** This field displays the program mode, either OFFLINE or ONLINE depending on whether the channel edit menu was invoked from the Offline or Online selection of the main development menu.
- SET-POINTS:** This a 10 row by 5 column, 50 element array where the set-points are entered using the various set-point programming commands.

Note: If the channel is not programmed as a pulse train (PULSE TRAIN = NO), that up to 50 unique set-points can be entered in the channel. If the channel is programmed as a pulse train (PULSE TRAIN = YES), up to the scale factor divided by two number of set-points (ON = 1, OFF = 1) can be programmed in the channel. In this case only the first 50 set-points would be displayed in the channel, however the channel would be programmed through-out with the "on" and "off" duration specified. See section 5.4 for complete details on the set-point programming commands.

If the channel is not programmed as a pulse train, a large block cursor is placed in the "ON" field of the currently selected set-point to be edited. This cursor can be moved to any set-point number using the cursor (arrow) left, right, up, and down keys. Whichever set-point the block cursor is located at is the set-point that the various set-point programming commands will operate on.

If the channel is programmed as a pulse train, the cursor will not be display at all. The only commands which are valid once a channel is programmed as a pulse train are the "F5: Pulse Train" and "F8: Clear Chan" commands. Thus the cursor is not used to select set-points since the commands that operate on individual set-points are not valid.

If no set-point is programmed at a given set-point number, the field is displayed as "____-____". Otherwise, as an example, the set-point will be displayed as 020-040 where 020 is the location the channel turns "on" and 040 is where the channel turns "off" for the given set-point.

- SCALE FACTOR:** This is the scale factor as entered in the PLS configuration.

Note: The scale factor cannot be changed from the channel edit menu, but is displayed only for reference.

SECTION 5

PLS PROGRAMMING

USING SYSdev

MESSAGE:	This is field which displays various status messages, informing the user of invalid commands (i.e., "invalid set-point"), operations in process (i.e., "loading file.."), etc.
OFFSET:	The current resolver offset of the selected program. This is entered using the "F10: Set Offset" command.
PULSE TRAIN:	Defines whether the channel is programmed as a pulse train (YES) or not (NO). The channel defaults to "NO" until the "F5: Pulse Train" command is executed. Once programmed as a pulse train, the channel must be cleared using the "F8: Clear Chan" command to reset PULSE TRAIN to "NO". See section 5.4 for details of the pulse train command.
ON:	"On" duration, in degrees, of the pulse train.
OFF:	"Off" duration, in degrees, of the pulse train.
START:	Starting location of the pulse train. The Channel will be programmed through-out with the "on" and "off" durations starting at the "Start" location.

The function key commands of the channel edit menu are defined as follows:

F1: Next Chan

Selects the next highest numbered channel for editing. When selected, the channel number will increment by one and the set-points and data for that channel will be displayed. The "PgDn" key also performs the same function as the "F1: Next Chan" key.

F2: Prev Chan

Selects the next lowest numbered channel for editing. When selected, the channel number will decrement by one and the set-points and data for that channel will be displayed. The "PgUp" key also performs the same function as the "F2: Prev Chan" key.

F3: Select Chan

Used to select any channel number for editing. When selected, the current channel number will be cleared and the cursor will be placed in the CHANNEL field. Simply type in the desired channel number, in octal, and press Enter<CR> to accept. The set-points and data for that channel will then be displayed.

F4: Doc Chan

Used to enter the channel description or name in the DESCRIPTION field. This is a user definition of the channel and will be associated with the channel at all times (print-outs, etc.). Up to 20 printable characters can be entered in this field. Once the name is entered, press Enter<CR> to accept.

F5: Pulse Train

Used to program the channel as a pulse train. See section 5.4 for details.

F6: Fine Tune

Used to fine tune (increment or decrement) the selected set-point. See section 5.4 for details.

SECTION 5

PLS PROGRAMMING

USING SYSdev

F7: Clear SetPnt

Clears the currently selected set-point (set-point designated with cursor). No other set-points are affected by this command.

F8: Clear Chan

Clears all the set-points in the channel. Also used to clear the channel and reset the pulse train mode to "no" when a channel has been programmed as a pulse train.

F9: POS/RPM

Active only in the on-line mode. Used to display the current resolver angular position and RPM. When pressed, a prompt in the message field will display both the position and RPM. This data is updated continuously. To exit the position and RPM display, simply press <ESC>.

F10: Set Offset

Used primarily in the on-line mode to electronically zero the resolver shaft at the machine zero. To set the offset, locate the machine at machine zero. Read the resolver shaft position, select "F10: Set Offset" and enter the position read into the offset field. The actual offset number, required to make this the zero position, will then be calculated by SYSdev and downloaded to the M4500. The actual offset (which may not equal the entered position) will be displayed in the offset field and the M4500 will then display zero as the position.

Alternatively, the resolver can be zeroed simply by entering the number 0 for the offset. The M4500 PLS contains an auto zero algorithm which will calculate the offset required to make the current position zero.

5.3 PLS CONFIGURATION

The PLS configuration is used to define the following PLS parameters in the M4500: PLS program selected, scale factor, number of PLS channels, and speed compensation for channels 00 through 07. The parameters are all set through the "Edit PLS Configuration" menu selection.

5.3.1 PLS PROGRAM

The M4500 supports up to 8 PLS programs. These can be called up by the user and mapped to the active timing channels. From SYSdev's point of view, each PLS program is one SYSdev PLS file. Thus if an M4500 was to be loaded with multiple PLS programs to be used, multiple files would be created, saved on disk, and down-loaded to the M4500. This selection simply specifies which PLS program the currently selected file is. If the M4500 is to use only one PLS program (as is generally the case), "PLS PROGRAM" should be set to 0. See section 3.1.4 for details on PLS programs.

5.3.2 SCALE FACTOR

The scale factor is the desired number of divisions per revolution. This is programmable from 2 to 4096. For 360 degrees per revolution, the scale factor should be set to 360.

5.3.3 NUMBER OF PLS CHANNELS

This is the number of PLS timing channels that will be used. The M4500 PLS supports either 8, 16, 32, or 64 timing channels. Enter one of these four numbers, as desired, for the number of PLS channels.

5.3.4 SPEED COMPENSATION

Independent Speed Compensation is available for timing channels 00 through 07. Each of these channels can be programmed to have from 0 to 255 milliseconds of timing signal "lead" (see section 3.1.5). The values entered for the speed compensation are in milliseconds. This is the amount of time that the timing signal will lead the programmed timing set-point as the speed of the machine is varied. The speed compensation for each channel is independently set. If speed compensation for a particular channel is not to be used, enter "0" for the compensation amount for that channel.

5.4 CHANNEL SET-POINT PROGRAMMING COMMANDS

Three channel set-point programming commands are available through SYSdev. These are: single set-point programming, set-point fine tune, and the pulse train programming command. The single set-point command allows the user to simply type in the complete set-point, both "on" and "off" parameters, at the currently selected set-point. The fine tune command allows the user to either increment or decrement by one the "on" or "off" set-point parameter of the currently selected set-point. The pulse train programming command allows the user to program the entire channel with a pulse train of a fixed "on" and "off" duration through-out.

SECTION 5

PLS PROGRAMMING

USING SYSdev

5.4.1 SINGLE SET-POINT PROGRAMMING COMMAND

The single set-point command is used to enter unique set-points in a channel when that channel is not programmed as a pulse train (PULSE TRAIN = NO).

Note: When the channel is programmed as a pulse train, the single set-point command cannot be used to modify individual set-points in the channel. To program a single set-point, locate the set-point cursor (large block cursor) at the set-point to be modified (the large cursor will always be located in the "on" parameter of the set-point). Enter the set-point as follows:

- 1) Type in "on" parameter in degrees (cursor will change to the small data entry cursor)
- 2) Press Enter<CR> or '-' to enter the "on" parameter.
- 3) Type in "off" parameter in degrees.
- 4) Press Enter<CR> to enter the "off" parameter.
- 5) The cursor will change back to the large set-point cursor and automatically advance to the "on" parameter of the next set-point. The set-point has now been entered.
- 6) If an invalid set-point number is entered, a message stating this will be displayed in the "message" field of the channel edit menu. Re-enter a proper set-point value or press "ESC" to abort the set-point entry

Note: The set-point values entered must be less than the scale factor. Set-points are also not allowed to overlap any existing set-points already entered in the channel.

Example #1: The following key sequence enters the set-point 020-040 at set-point number 1:

<u>Key Depressed</u>	<u>Set-point Field</u>
	____-____
2	2____-____
0	20____-____
-	020____-____
4	020-4____
0	020-40____
Enter<CR>	020-040

Example #2: The following example programs the entire channel "on" by specifying both the "on" and "off" parameters to 000:

<u>Key Depressed</u>	<u>Set-point Field</u>
	____-____
0	0____-____
Enter<CR>	000____-____
0	000-0____
Enter<CR>	000-000

5.4.2 FINE TUNE SET-POINT COMMAND

The fine tune set-point command allows the user to increment or decrement by one the "on" or "off" parameter of an already existing set-point. The fine tune command is executed by selecting "F6: Fine Tune" from the channel edit menu. When this is done, the fine tune menu is displayed. This menu contains the following commands:

F1: On Setpnt

This is used to select the "on" parameter of the set-point. When selected, the cursor will move to the least significant digit of the "on" parameter.

F2: Off Setpnt

This is used to select the "off" parameter of the set-point. When selected, the cursor will move to the least significant digit of the "off" parameter.

F3: (+) Inc

This command increments the selected parameter (either "on" or "off", whichever was selected with the On Setpnt or Off Setpnt commands) by one.

F4: (-) Dec

This command decrements the selected parameter (either "on" or "off", whichever was selected with the On Setpnt or Off Setpnt commands) by one.

The fine tune command is primarily used in on-line mode to fine tune set-points while the machine is in operation.

SECTION 5

PLS PROGRAMMING

USING SYSdev

5.4.3 PULSE TRAIN COMMAND

The pulse train command is used to program a channel with a fixed "on" and "off" duration through-out the entire channel in one simple command. To program a channel with a pulse train perform the following:

- 1) Select "F5: Pulse Train" from the channel edit menu.
- 2) The cursor is located in the "ON:" field of the channel edit menu. Enter the "on" duration in degrees and press Enter<CR>.
- 3) The cursor is located in the "OFF:" field of the channel edit menu. Enter the "off" duration in degrees and press Enter<CR>.
- 4) The cursor is now located in the "START:" field. Enter the location that the pulse train will be initially started at in degrees and press Enter<CR>.
- 5) The entire channel will be programmed with the "on" and "off" duration through-out the entire channel starting at the "start" location. The first 50 set-points (or less) will be displayed in the set-point array.

Note: The set-point cursor will not be displayed since the single set-point and fine tune commands are not valid if the channel is programmed as a pulse train.

SECTION 6

FAULT DETECTION

The M4500 modules contain comprehensive fault detection routines which verify the proper operation of the module at all times. If the module detects a fault condition, the "FLT" LED on the front of the module is illuminated and the fault routine is executed. The sources of these faults range from a hardware failure of the module to an error in the user's program (infinite loop, etc.).

6.1 FAULT ROUTINE EXECUTION

When a fault is detected, the following fault routine is executed:

- 1) User program execution is suspended.
- 2) If possible, all outputs in the system are disabled
- 3) "FLT" LED on the front of the module is illuminated.
- 4) "RUN" LED is extinguished.
- 5) Fault interlock is opened
- 6) Fault code representing the detected fault is saved in internal memory of the module for viewing with SYSdev.

The first step in correcting a fault condition (FLT LED "on") in an M4500 module, is viewing the fault code saved inside the module with SYSdev.

6.2 VIEWING FAULT CODES WITH SYSDEV

When a fault occurs, an IBM PC or compatible, running SYSdev, can be connected to the PROG port of the module to view the fault codes. To view the fault codes, perform the following:

- 1) Connect IBM PC "COM" port to M4500 "PROG" port using the appropriate cable (see appendix B).
- 2) Initiate SYSdev from the DOS prompt and select the user program currently loaded in the module.
- 3) From the main menu, select "6: Target Board Interface".
- 4) From the Target Board Interface menu, select "4: Target Board Fault Codes/Status".

SECTION 6

FAULT DETECTION

The SYSdev fault display reads the fault codes from the module and displays the following:

Target Board Internal Fault Code

- 1) Curr Flt:
- 2) Last Flt:
- 3) Co-cpu slot:
- 4) Corrective action:

Communications Network Error Codes

- 5) Current comm error:
- 6) Last comm error:

Curr Flt: This is the M4500 fault code corresponding to the current detected fault along with a short description of the fault. This fault code is cleared at power-up or optionally by the user after it is displayed in the SYSdev fault display.

Last Flt: This is the last M4500 fault code detected, shown just as the Curr Flt is shown. Unlike the Curr Flt, this fault code is not cleared at power-up. This field retains the last detected fault even when power to the module is cycled. This fault code can only be cleared after it is displayed in the SYSdev fault display.

Co-cpu slot: Not used by the M4500 modules.

Corrective action: This field contains a short description of the action which can be taken to correct the particular fault that was detected.

Current comm error: This field displays the current serial network comm error along with a short description describing the error. This field is cleared as soon as the current comm error clears.

Last comm error: This field displays the last error displayed in the Current comm error field. Unlike the Current comm error, this field retains the error code even after the error condition clears. This provides a history of the last comm error to occur.

The user has the option of clearing the fault codes when exiting the SYSdev fault display.

6.3 FAULT CODES

The following is a list of the fault codes and descriptions, as displayed in the SYSdev fault display, detected by the M4500 modules:

<u>Code</u>	<u>Description</u>
00H	No internal fault has occurred
40H	Watchdog timer timeout
42H	Cannot communicate with target board
44H	Program memory checksum error
45H	User program system fault sfunc09 call
59H	Program execution out of bounds
5AH	Address out of program memory range
5BH	Invalid interrupt
5CH	Program invalid - execution suspended
5DH	Program dump timeout - program not sent

6.3.1 WATCHDOG TIMER TIMEOUT (40H)

The watchdog timeout fault occurs when the main program scan time exceeds 50 milliseconds. The cause of this fault ranges from an error in the user program (unintentional loop entered in the user program, unintentional indirect access to program memory) to a hardware failure of the M4500 module.

Trouble-Shooting:

- 1) Check the program for any unintentional loops. These are loops where the exit condition of the loop can never be satisfied. This can occur in "for", "while" and "do-while" loops. Also check for any "goto" jumps that cause the program to jump to a previous location in the program with no condition to stop executing the jump.
- 2) Check for any loop instructions that may take longer than 50 milliseconds to execute (a large number of iterations through the loop).
- 3) If the problem persists, try another M4500 module to verify if a hardware problem exists.

SECTION 6

FAULT DETECTION

6.3.2 IBM PC TO M4500 COMMUNICATIONS FAILURE (42H)

If an attempt to read the fault codes from the M4500 module results in an error code of "42H: Cannot communicate with target board", the PC cannot communicate with the module. This is not an internal M4500 fault but instead a fault detected by SYSdev. The cause of this fault ranges from catastrophic failure of the module to a misconnection of the PC to the module.

Trouble-Shooting:

- 1) Verify the "PWR" LED on the module is on. If not, verify that +5VDC power is applied to the module.
- 2) Verify that the RS-232 cable is connected to the proper "COM" port on the PC and "PROG" port on the module.
- 3) Verify that the RS-232 cable connecting the PC to the module is wired correctly. See appendix B for the pin out of the cable.
- 4) If the above verifies, replace the M4500 module and try again. If the problem still persists, verify the "COM" port for proper operation (see manual from PC manufacture).

6.3.3 INVALID PROGRAM FAULTS (5CH and 5DH)

The "Program invalid" (5CH) fault occurs when the module does not contain a valid user program. This typically occurs when a new module is installed which has never had a user program downloaded to it or after the hardware confidence test is performed, which erases the program memory. The "Program dump timeout" (5DH) fault occurs when program download to the M4500 module is interrupted while program download is in progress.

Trouble-Shooting:

- 1) Dump the user program to the M4500 module. These faults will clear once the module is loaded with a valid user program.
- 2) If re-loading the module with the user program does not clear the fault, replace the M4500 module and try again.

6.3.4 USER PROGRAM sfunc09 SYSTEM FAULT CALL (45H)

This fault code is set when the user program performs an sfunc09(); system function fault call. See the user program for the purpose of the system fault call. See the M4500 Program Development manual for details on sfunc09.

6.3.5 INTERNAL M4500 FAULTS (44H,59H-5BH)

The remainder of the fault codes detected by the M4500 module represent an internal failure of the module. These can range from the RAM battery low to invalid interrupt requests.

Trouble-Shooting:

- 1) Perform the hardware confidence test on the M4500 module. It may be desirable to remove the suspect module from the system and to install another module to get the application being controlled back up and running. See section 7 for details on the test.
- 2) Based on the results of this test, return the module for repair, or re-install the module in system.

6.4 SERIAL NETWORK COMMUNICATION ERRORS

The serial network communications occur in conjunction with the network port on the optional S4516 Communications board. Unlike the system faults, the serial network communication errors do not cause the M4500 module to shut-down, but instead are simply logged into the Current and Last comm error registers, with user program execution continuing. The Current comm error represents an error that is present at the time the fault codes are viewed, while the Last comm error represents the last comm error detected. The comm error codes are viewed from the SYSdev fault display, see section 6.2 for more details.

The error codes saved in the Current and Last comm error registers are the same error codes returned from the sfunc13 call. The return values from the sfunc13 calls should be saved in separate 'B' variables such that when a comm error occurs, the slave that it occurred with can be determined.

SECTION 6

FAULT DETECTION

6.4.1 SERIAL NETWORK COMM ERROR CODES

The following is a list of the detected serial network communication errors:

<u>Code</u>	<u>Description</u>
00H	No network comm error
03H	More than one bus master detected
04H	sfunc13 xmitt timeout - no response
05H	sfunc13 receive timeout - no response
06H	Invalid command received from master
07H	Receive overflow
08H	Receive collision detected
09H	Receive alignment error (bad frame)
0AH	Receive CRC error
0BH	Unknown (undefined) error
0CH	Transmit no acknowledge
0DH	Transmit under run error
0EH	Transmit collision detected
0FH	Address error (outside data memory)
10H	Unexpected slave responding

6.4.2 NO RESPONSE FROM SLAVE (04H and 05H)

The no response errors occur when the master executes an sfunc13 addressed to a particular slave but receives no response from that slave. For every execution of sfunc13, the slave will always respond to the request, even if no data is to be sent from the slave to the master. This verifies that the slave did, in fact, receive the data sent to it.

Trouble-Shooting:

- 1) Verify that the network continuity is good between the master and the slave. This can be done by observing the "COMM" LED's on the network interface boards. Every time sfunc13 is executed, the "COMM" LED's will flash (or be on solid for continuous communications).
- 2) Verify that the master and all slaves on the network are set to the correct network address they have been assigned. For each node on the network, the address must be a number between 1 and 32 and must be unique. See section 8.8.2.
- 3) If the problem persists, replace the S4516 in the slave M4500 module where the problem is occurring. Next replace the S4516 in the M4500 master module.

6.4.3 SERIAL NETWORK INTEGRITY ERROR (03H, 06H-0EH, 10H)

The serial network integrity errors occur when corruption of the transmitted frame is detected. The sources of these errors range from multiple masters attempting communications on the network to excessive induced EMI on the network.

Trouble-Shooting:

- 1) Verify that only one master is communicating on the network. The master is defined as the node which is executing the sfunc13 system functions. If two nodes are executing sfunc13s simultaneously, a network collision will occur with the corresponding corruption of data.
- 2) Verify that the network wiring is isolated from other high voltage wiring which could induce EMI into the network. The network should be routed in a conduit separate from other wiring.
- 3) Replace the S4516 in the slave M4500 module with which the error occurred. If the problem persists, replace the S4516 in the M4500 module at the master node.

6.4.4 ADDRESS OUTSIDE RANGE (0FH)

This error occurs when an attempt to write to memory outside the data memory range occurs in either the master or slave. Verify the corresponding sfunc13 call specifies the proper data range.

SECTION 6

FAULT DETECTION

(This Page Intentionally Left Blank)

SECTION 7

HARDWARE CONFIDENCE TEST

The hardware confidence test allows the internal M4500 module hardware to be verified for proper operation. The test is resident in all modules and is initiated through SYSdev. The hardware confidence test is the same test used at the factory to initially test the production M4500 modules, and therefore provides the same hardware test as provided at the factory.

The test is provided to the user to verify whether the module hardware is functional or not. Not as a tool to repair the modules. If a fault is detected, the module should be returned to the factory for repair. Any attempt to repair an M4500 module will void the warranty.

7.1 TESTS PERFORMED

The following is a list of the tests performed by the hardware confidence test:

- 1) Microcontroller RAM test
- 2) Internal Fault detection test
- 3) RAM memory test
- 4) RS-232 PROG PORT test

Tests 1, 3, and 4 are not optional and are always performed. Test 2 is normally enabled but can be disabled if desired.

Note: If test 2 is to be performed, the FLT interlock output must be wired to the '-' terminal of both the interrupt input0 and input1 inputs. The '+' terminals of both interrupt input0 and input1 must be wired to the '+' terminal of the fault power input (+24VDC). Test 2 uses these two inputs to verify the FLT interlock output. Failure to connect these inputs as described will result in a fault detected when test 2 is performed. All tests are automatic and require no interaction once the test is initiated.

Each test performs a complete check of the respective hardware area of the module. If a fault is detected, the test is stopped and a test fault code is displayed to indicate the nature of the hardware failure.

Note: The actual input and output points hardware is not checked with these tests. This can be done using the on-line monitoring mode of SYSdev to view the states of the inputs and set the states of the outputs.

SECTION 7

HARDWARE CONFIDENCE TEST

7.2 PERFORMING THE HARDWARE CONFIDENCE TEST

WARNING: The hardware confidence test should not be performed in an M4500 module installed in a user's control system. Unpredictable output states may result while the test is being performed.

7.2.1 EQUIPMENT REQUIRED

In order to perform the hardware confidence test, the following is required:

- 1) IBM PC or compatible with SYSdev installed.
- 2) RS-232 interface cable to connect the "COM" port on the PC to "PROG" port on the M4500 module.
- 3) +24VDC power supply to power fault interlock.
- 4) M4500 module to be tested.
- 5) P4500 power supply to power M4500 module.

7.2.2 EXECUTING THE TEST

To execute the test, perform the following steps:

- 1) Power up the M4500 module to be tested.
- 2) Power up PC and enter SYSdev. Enter any user program name to proceed to the SYSdev Main Development Menu.
- 3) Connect Interface cable to the "COM" port on the PC and "PROG" port on module.
- 4) Select "6: Target Board Interface" from the Main Development Menu then select "7: Target Board Hardware Confidence Test" from the Target Board Interface menu.
- 5) Select "M4500 Confidence test" from the confidence test menu. A prompt will be displayed verifying to proceed with the test.

Note: Proceeding with the test will clear the program and data memory in the module. The user application program will have to be re-downloaded to the module once the test is complete. Press "ESC" to abort the test, any other key to proceed.

- 6) Select "Perform Test" from the Test Functions Menu to start the test. Once the test is initiated, all tests enabled will be executed repeatedly, starting with test1 thru the last enabled test, until any key is depressed.

If no faults are detected, the tests will continue to execute repeatedly, displaying "test passed" messages after the successful completion of each test. If a fault does occur, the test will stop and display the following:

Fault Code = XX (test fault code and description)

Address of fault.....: (memory address or I/O address where fault occurred)

Actual data at fault: (data actually obtained at address of fault)

Expected data at fault: (data that should have been obtained at address of fault)

Diagnostics test number: (for factory use only)

Once a fault occurs, exit back to the Main Test Menu and re-initiate the test to reset the fault code.

Once testing is complete, exit back the Main Development Menu. The user application program will now have to be re-downloaded to the M4500 module.

SECTION 7

HARDWARE CONFIDENCE TEST

(This Page Intentionally Left Blank)

SECTION 8 INSTALLATION

The following sections provide information on mounting and wiring the M4500 modules as well as a description of the power-up sequence.

Note: All wiring is implemented with removable field wiring connectors. Refer to appendix C for the pin-outs of the various connectors on the M4500 modules.

8.1 MOUNTING THE D4590/D4591/M4502/M4503 KEYPAD/DISPLAYS

The D4590 and D4591 displays were designed to be mounted to the back of the M4500/01 or M4508/09 modules respectively. Alternatively, the M4500 modules could be mounted to the back-panel with the D4590/91 mounted in the user's cabinet door. The displays are interfaced to the M4500 via a 26 pin ribbon cable. Communications is parallel at TTL levels therefore the display must be placed in close proximity to the M4500 (maximum cable length is 8 feet).

The M4502 and M4503 are equipped with built-in D4591 Display/Keypads and are therefore mounted in the user's cabinet door in the same fashion as the D4591 display.

8.1.1 INSTALLING THE KEYPAD LEGEND BEHIND THE OVERLAY

Customization of the keypad legends is implemented with a keypad placard that is placed between the keypad overlay and the keys themselves. Depending on the application, the keypad/displays are provided either with or without the keypad placard. The user can generate keypad placards using a word processor or desk top publishing software package. If the keypad placard needs to be installed or changed, perform the following to install the keypad placard:

- 1) For the M4502 and M4503 only: The D4591 must be removed from the module prior to performing the following steps. To remove the D4591 from the M4502/03, remove the six 6-32 screws which retain the D4591 in the module and then disconnect the 26-pin ribbon cable at the back of the D4591 display.
- 2) Remove the four 6-32 screws shown in figure 8.1 from the back of the D4590/91. These four screws hold the display bezel to the display body. Do not remove any of the other screws.
- 3) Place the keypad placard in the opening of the display bezel behind the overlay where the keypad is located, aligning the placard with the keypad key openings.
- 4) Install the display bezel back onto the display body and install the four 6-32 screws that hold the bezel to the display body. The keypad placard will now be sandwiched between the overlay and the keys. Prior to tightening the four screws, align the display body (display and keypad) with the bezel. Now tighten the four screws.

SECTION 8 INSTALLATION

8.1.2 MOUNTING THE KEYPAD/DISPLAYS IN THE CABINET DOOR

The D4590 and D4591 keypad/displays are designed to mount from the front in the user's cabinet door. Use the recommended cut-outs in figures 8.2 and 8.3 for the D4590 and D4591 respectively. Remove the ribbon cable from the D4590/91. With the gasket installed on the keypad/display mounting studs, slide the D4590/91 into the cut-out from the front. Attach the D4590/91 to the door with supplied hardware. Install the 26-pin ribbon cable back in the D4590/91 connector (the ribbon cable connector is polarized and will mate with the connector only one way). Once the keypad/display is installed, a lugged earth ground wire should be installed on one of the mounting screws to insure that the keypad/display is grounded.

SECTION 8 INSTALLATION




Figure 8.1 - D4590/D4591 Keypad/Display Bezel Removal

SECTION 8 INSTALLATION




Figure 8.2 - D4590 Keypad/Display Recommended Panel Cut-Out




Figure 8.3 - D4591 Keypad/Display Recommended Panel Cut-Out

8.2 MOUNTING THE M4500 CHASSIS

The M4500 chassis were designed for either back panel mounting or mounting to the user's cabinet door, behind the D4590/91 display.

8.2.1 INSTALLING OPTIONAL CIRCULATION FAN

In high power applications (driving high current loads with outputs), the optional circulation fan should be installed to draw the heat generated from the output boards out of the chassis. If not already installed, the fan is mounted in two mounting holes centered in the upper lip of the chassis and is cantilevered over the chassis such that air is drawn up from the chassis through the fan. The fan is powered from +24VDC and should be connected to the fault power terminals of the M4500. The red lead of the fan is the (+) power lead while the blue lead is the (-).

8.2.2 BACK-PANEL MOUNTING THE M4500 CHASSIS

If mounting to a back-panel, the chassis should be mounted using 4ea. 8-32 screws and lock washers. If the M4500 is to be connected to a D4590/91 keypad/display, connect the ribbon cable for the display to the M4500 display interface connector prior to mounting the M4500 chassis. The ribbon cable connector is polarized and should mate with the M4500 display interface connector only one way. Once the M4500 chassis is installed, a lugged earth ground wire should be installed on one of the mounting screws to insure that the chassis is grounded.

8.2.3 DOOR MOUNTING THE M4500 CHASSIS

If mounting to the D4590/91, the M4500 chassis is mounted to the mounting studs of the display (4 places) with the M4500 chassis mounted to the inside of the door (door sandwiched between D4590/91 and M4500 chassis (see figure 8.4). Prior to mounting the M4500 chassis to the back of the D4590/91 keypad/display, connect the ribbon cable from the display to the M4500 module display interface connector (located on the back of the M4500 module). The ribbon cable connector is polarized and will only mate with the M4500 display interface connector one way. Once the M4500 chassis is installed, a lugged earth ground wire should be installed on one of the mounting screws to insure that the chassis is grounded.

SECTION 8 INSTALLATION




Figure 8.4 - M4500 With Keypad/Display Door Mount Detail

8.3 MOUNTING P4500 POWER SUPPLY

The P4500 power supply can either be mounted with the left hand mounting holes of the M4500 chassis or in separately drilled holes for the power supply. In both cases, the power supply must be located to the left of the M4500 chassis in close proximity to the chassis (see appendix C). If mounting the P4500 in separate mounting holes, use 2ea. 8-32 screws and lock washers to mount the P4500. Once mounted, connect the power supply cable connector in the +5/C/+12/C/-12 connector of the M4500. The connector is polarized and will only mate one way.

Wire 115VAC/230VAC 40-400HZ power to the P4500 power connector. The AC current rating is 0.5 amps at 115VAC and 0.3 amps at 230VAC.

8.4 INSTALLING I/O BOARDS IN M4500 CHASSIS

Once the M4500 chassis is mounted, the digital input and output boards as well as the S4516 Communications board are installed. Refer to the individual data sheets for the I/O boards in appendix A for complete details on installing and wiring the I/O boards.

Once the I/O boards are installed, apply the I/O identification labels to the respective slots where the I/O boards are installed. This specifies the I/O board part number and slot that the I/O board is addressed as.

SECTION 8 INSTALLATION

8.5 WIRING INTERRUPT INPUTS

Interrupt input0 and input1 are 10-30VDC differential inputs which can be wired as sourcing (true high), sinking (true low), or as true differential inputs (driven by a differential output). Each input is provided with a '+' and '-' terminal. Figure 8.5 shows wiring examples of all three types of input configurations.




Figure 8.5 - Typical Interrupt Input Wiring

8.6 WIRING ANALOG I/O

Two analog inputs and two analog outputs are built into the M4500. The analog inputs are 0-5 volt which can be used as 0-20ma and 0-10 volt inputs when external resistors are installed to perform the respective conversion. The analog outputs are 0-10 volt which can be used to drive 0-10 volt analog inputs or 0-5 volt analog inputs using a similar external resistor conversion. Figure 8.6 shows wiring examples of both the analog inputs and analog outputs.




Figure 8.6 - Typical Analog I/O Wiring

SECTION 8 INSTALLATION

8.7 WIRING THE FAULT INTERLOCK

The fault interlock is a +24VDC sinking (true low) output which can be interfaced to an external relay or PLC input to indicate a fault condition with the M4500 module. The output is capable of sinking 500 milliamps. The fault output is "on" (true low - sinking current) when the module is executing the user program properly. If a fault condition is detected, the fault output is turned "off" (high). Figure 8.7 shows the fault output wired to a +24VDC relay. This relay could be interlocked with the digital outputs power to remove power from the outputs if the module was to fault out.




Figure 8.7 - Typical Fault Interlock Wiring

8.8 SERIAL NETWORK INSTALLATION

If the S4516 communications board will be used to communicate to other S3000 processors/M4000 or M4500 modules, the serial network will have to be installed. The serial network installation consists of wiring the network and setting each S3000 board/M4000 module on the network with a unique network address. Up to 32 S3000 boards/M4000 modules can be installed on one network.

8.8.1 WIRING THE SERIAL NETWORK

Refer to figure 8.8 for a typical schematic of the network and for the pin outs of the network interface connectors. When wiring the network, the following rules must be followed:

- 1) Wire the network using Belden #9182 single-shielded twisted pair cable or an equivalent data communications cable meeting the following spec:

Wire gauge: 22AWG
Nom. impedance: 150 ohms/ft.
Nom. attenuation at 1MHZ: .004 db/ft.
Twisted pair, single-shielded

- 2) The total wire length of the network cannot exceed 1000 ft. if the network baud rate is set to 344KBPS, 2000 ft. for 229KBPS, and 4000 ft. for 106KBPS. See section 8.8.2 for details on setting the network baud rate.
- 3) The maximum number of nodes connected to one network is limited to 32 nodes.
- 4) The shield of the cable should be carried through the entire network, using the shield tie points on the interface connectors to achieve this. The shield tie-points on the connectors are not internally tied to anything, they are strictly tie points. One of these tie points should then be tied to earth ground.
- 5) The two extreme ends of the network should be terminated with 150 ohm resistors as shown in figure 8.8.
- 6) The network wiring should be isolated from other high voltage wiring by routing the network in a separate conduit dedicated to the network.
- 7) The network should be wired directly to the network comm port connectors. No intermediate terminations or splices should be used. The network should be wired in a direct connect topology as shown, not in multi-drop or cluster topologies.

Note: The network comm interface connectors contain two sets of + and - terminals. The two sets of terminals are tied together internally on the module (+ to +, - to -) and are provided as tie points to ease wiring. Communications across the network will continue even if one of the nodes has failed provided all the connectors are installed in their respective module. However, if a connector is pulled from it's module, communications to the modules downstream will be lost (the internal tie point will be broken). If it is desired, this situation can be avoided by wiring the connector as shown in figure 8.9.

SECTION 8 INSTALLATION




Figure 8.8 - Typical Network Wiring




Figure 8.9 - Alternative Serial Connector Wiring

8.8.2 SETTING THE NETWORK ADDRESSES

Each S3000 board/M4000 module on the network must be set with a unique network address between 1 and 32. This is how the modules can distinguish one node from another. To set the network address for a particular module, perform the following:

- 1) Connect an IBM PC or compatible running SYSdev from the "COM" port on the PC to the "PROG" port on the module using the RS-232 interface cable (see appendix B).
- 2) From the SYSdev Main Development Menu, select "6: Target Board Interface".
- 3) From the Target board Interface Menu, select "5: Target board Network Address".
- 4) SYSdev will read the current network address of the S3000 board/M4000 module and display it in the network display. If the network address is to be changed, follow the directions displayed and enter the new address.

The above steps must be done for all S3000 boards/M4000 modules on the network. This is true when the network is first installed, and when a new module is added or replaced (that module must have the network address set it in).

The M4500 modules network address is set via sfunc19 in the user's PLC application program. Refer to the application program for details on setting the M4500 network address.

8.9 RESOLVER INTERFACE

The M4500 PLS is generally interfaced to the RSV34-MS1 resolver but can be used with virtually any type of resolver which incorporates a rotor reference signal and two stator feedback signals. Separate resolver reference input and output connections are provided on the resolver interface connector. This allows The M4500 modules to be slaved to other M4500 modules or to other manufactures programmable limit switches off one resolver.

SECTION 8 INSTALLATION

8.9.1 RESOLVER WIRING

Figure 8.10 shows the typical wiring to a generic resolver for stand alone operation (M4500 PLS provides reference voltage for resolver).

Note: The reference output (RO) is tied to the reference input (RI). The reference output excites the resolver while the reference input and two stator inputs are used to determine the absolute position of the resolver. The direction of rotation is determined by the connection S1 and S3. Swapping S1 and S3 will reverse the direction of rotation for the M4500 module.

Figure 8.11 shows two M4500 modules wired to one resolver with module #2 slaved to module #1 (reference for resolver supplied by module #1). In this case the reference output (RO) of module #1 is connected to the resolver and tied to the reference inputs (RI) of both modules while the reference output of module #2 is not used. Up to 8 modules can be slaved off one resolver this way. In all cases, a shielded twisted pair cable should be used to wire the resolver to the M4500, making sure the cable is routed free of other high voltage wiring.

SECTION 8 INSTALLATION




Figure 8.10 - M4500 Resolver Interface (Stand Alone)




Figure 8.11 - Two M4500 Slaved To One Resolver

SECTION 8 INSTALLATION

8.10 POWER-UP SEQUENCE OF M4500 MODULES

Once all connectors are wired and re-installed in their respective sockets, apply 115/230VAC power to the P4500 power supply. The power-sequence occurs as follows:

- 1) At initial power-up, the module is reset for approximately half a second. During this time, the fault interlock will be "off", and the "FLT", "RUN" and "PWR" LED's will all be "on". The outputs will also all be "off".
- 2) Once the reset cycle is complete, the module will begin to execute the program previously loaded. The fault interlock will turn "on" (sink true low) and the "FLT" LED will extinguish. The outputs will then be activated in the states as controlled by the user program.
- 3) If a user program has not been loaded (new module or module which the confidence test has just been executed), the "FLT" LED will stay "on" and the "RUN" LED will extinguish. Download the user program and data files to the module. The "RUN" LED will flash while the user program is downloading. When the download is complete, the "FLT" LED will extinguish and the "RUN" LED will turn "on". If the "FLT" LED turns "on" after the download is complete, read the fault code in the M4500 module (see section 6). See the SYSdev program manual for details on downloading programs to the M4500 modules.

S4516: SERIAL COMMUNICATIONS BOARD
S3000 NETWORK PORT AND RS-232/RS422 USER PORT

FEATURES

- One S3000 Serial Network Port and One RS-232/RS-422 User Port
- S3000 Network Port Configurable For 106kbps, 228kbps, Or 344kbs
- RS-232/RS-422 Port Configurable For 9600 Or 19.2k Baud
- RS-232/RS-422 Data Receive and Transmit LED's
- Serial Network Comm Led
- Removable Field Wiring Connectors
- Standard M4500 I/O Form Factor

GENERAL DESCRIPTION

The S4516, for use with the M4500 series of modules, contains one S3000 Serial Network Interface port and one RS-232/RS-422 User Port. The S4516 provides a means for an M4500 module to communicate to other S3000, M4000, or M4500 modules/processors via the S3000 serial network. The RS-232/RS-422 port allows communications to other PLC or host computers. Multiple S4516 boards can be installed in one M4500 (up to the number of slots for that particular model) to allow the use of multiple S3000 network ports or RS-232/RS-422 User ports.

The serial network port conforms to the S3000-N1 network protocol. This network is a high speed (up to 344KBPS), twisted pair, serial network configured in a master/slave topology. Up to 32 M4500, S3000, or M4000 modules/processors (nodes) can be connected on one network. Communications between the nodes on the network is controlled via commands (sfunc13) in the user application program resident in the node acting as the master. The serial network baud rate is software configurable (via the user's program in the M4500) for either 106KBPS, 229KBPS, or 344KBPS.

APPENDIX A

S4516: SERIAL COMMUNICATIONS BOARD

The USER port is available as a general purpose RS-232/RS-422 port accessed under software control of the user program. Typical uses of this port are connection to other control equipment, data acquisition to a host PLC, etc.. Drivers are available for this port that implement the MODBUS protocol and the Allen-Bradley DF1 protocol. The USER port is dip switch selectable for either RS-232 mode or RS-422 mode. The USER port supports a frame format consisting of 1 start bit, 8 data bits, 1 stop bit, and no parity. An addition, the baud rate is software configurable (via the user's program in the M4500) for either 9600 Baud or 19.2K Baud.

Access to the serial network port is implemented via sfunc13 in the M4500 user's program while access to the USER port is implemented with sfunc10 (USER port read) and sfunc11 (USER port write). Configuration of the S4516 (network address, network baud, and USER port baud) is performed using sfunc19 in the M4500 user's program. Refer to the M4500 Program Development Manual for complete details on these system functions.

INSTALLATION

Prior to installing the S4516, the I/O slot addressing dip switch on the board must be set for the slot the board will be addressed as.

Note: Geographical addressing is not used in the M4500. The slot the S4516 is addressed as is solely defined by the dip switch settings on the S4516 itself not by the slot in the M4500 chassis that the board is placed in. Two poles on the dip switch of the board set the binary slot address of the board as follows:

Dip Switch Slot Addressing (SW2):

<u>2</u>	<u>1</u>	<u>Slot Address</u>
off	off	0
off	on	1
on	off	2
on	on	3

The SW2 Slot address dip switch is located in the lower right hand corner of the component side of the S4516. The respective switch pole is "on" when in either the "on" or "close" position and "off" when either in the "off" or "open" position depending on the type of dip switch used.

RS-232/RS-422 Dip Switch (SW1): This must also be set depending on whether the RS-232 mode or RS-422 is used. Two poles on SW1 define the mode. Pole 1 is for the RS-232 mode, pole 2 is for the RS-422. To select a specific mode, set the corresponding pole "on" or "closed". Not that only one mode can be selected, therefore the pole for the mode not used must be set "off" or "open".

APPENDIX A

S4516: SERIAL COMMUNICATIONS BOARD

To install the S4516 in the M4500 chassis, turn power to the M4500 "off" and remove the cover plate of the M4500 by loosening the captive screws that retain it. Install the S4516 in the respective slot of the M4500, making sure the DIN connector on the S4516 fully mates with the DIN connector in the M4500 motherboard and that the top of the S4516 is seated correctly in the card guides at the top of the M4500. Install the M4500 cover back onto the M4500 making sure the LED's and Field connector protrude through the respective openings in the cover. The M4500 cover will retain the S4516 both from the top and the front, holding the S4516 in place during normal operation. Tighten the captive screws that retain the cover on the M4500. Install the S4516 overlay on the M4500 cover at the slot the S4516 is installed in. Install the female field wiring connectors to the corresponding male connectors on the S4516. The S4516 is now installed and ready to run. To remove the S4516, simply perform the previous steps in reverse.

APPENDIX A

S4516: SERIAL COMMUNICATIONS BOARD

SPECIFICATIONS

Board Size:

Length:	6.50"
Height:	4.25"
Width:	0.80"

Serial Network Port:

Type:	RS-485
Comm Rate:	344KBPS, 229KBPS, or 106KBPS
# of nodes (max):	32
Isolation:	2000 VRMS
Distance:	1,000 ft., 2,000 ft., 4,000 ft.
Protocol:	Proprietary

USER Port:

Type:	RS-232/RS-422 selectable
Comm Rate:	9600 Baud 19.2K Baud
Start Bits:	1
Data Bits:	8
Stop Bits:	1
Parity:	None

Power Requirements:

Icc (typ - M4500 BUS):	150 milliamps
------------------------	---------------

Temperature Ranges:


Storage:	0 to 85 degrees C
Operating:	0 to 60 degrees C

Relative Humidity:


	5 to 95% non-condensing
--	-------------------------

APPENDIX A

S4516: SERIAL COMMUNICATIONS BOARD



S4516 Faceplate



S4516 Board Outline

APPENDIX A

S4516: SERIAL COMMUNICATIONS BOARD

(This Page Intentionally Left Blank)

S4563: DIGITAL DC INPUT BOARD
16-POINT 10-30VDC SOURCING

FEATURES

- 16 Digital Input Points
- 16 Individual Status LED's (1 Led Per Input Point)
- Removable Field Wiring Connector
- Optical Isolation
- Standard M4500 I/O Form Factor

GENERAL DESCRIPTION

The S4563 10-30VDC Input Board, for use with the M4500 series of modules, contains 16 identical solid state input circuits which accept the on/off status of user devices such as push-buttons, limit switches, and proximity sensors. The inputs sense the voltage levels of digital DC input signals, with the devices driving the inputs being defined as sourcing (positive current into the input). When the voltage at the input is high (above the input "on" threshold), the input is read as a "1". When the input is low (approximately zero), the input is read as a "0".

The on/off status of each input is indicated with individual LED's located on the front of the board. The LED's provide the status of the actual input points (field side) rather than the internal logic status. Input and user power wiring is implemented with a removable 18-pin field wiring connector which allows easy board replacement.

The 16 input points are read in the two least significant bytes of the slot that the board is addressed as. Inputs 0 through 7 are mapped in bits 0 through 7 of byte 0 of the slot, while inputs 10 through 17 are mapped in bits 0 through 7 of byte 1 of the slot.

APPENDIX A

S4563: DIGITAL DC INPUT BOARD

INSTALLATION

Prior to installing the S4563, the I/O slot addressing dip switch on the board must be set for the slot the board will be addressed as.

Note: Geographical addressing is not used in the M4500. The slot the S4563 is addressed as is solely defined by the dip switch settings on the S4563 itself not by the slot in the M4500 chassis that the board is placed in. Two poles on the dip switch of the board set the binary slot address of the board as follows:

S4563 SW1 Dip Switch Slot Addressing

<u>2</u>	<u>1</u>	<u>Slot Address</u>
off	off	0
off	on	1
on	off	2
on	on	3

The SW1 Slot address dip switch is located in the lower left hand corner of the component side of the S4563. The respective switch pole is "on" when in either the "on" or "close" position and "off" when either in the "off" or "open" position depending on the type of dip switch used.

To install the S4563 in the M4500 chassis, turn power to the M4500 "off" and remove the cover plate of the M4500 by loosening the captive screws that retain it. Install the S4563 in the respective slot of the M4500, making sure the DIN connector on the S4563 fully mates with the DIN connector in the M4500 motherboard and that the top of the S4563 is seated correctly in the card guides at the top of the M4500. Install the M4500 cover back onto the M4500 making sure the LED's and Field connector protrude through the respective openings in the cover. The M4500 cover will retain the S4563 both from the top and the front, holding the S4563 in place during normal operation. Tighten the captive screws that retain the cover on the M4500. Install the female field wiring connector to the corresponding male connector on the S4563. The S4563 is now installed and ready to run. To remove the S4563, simply perform the previous steps in reverse.

APPENDIX A

S4563: DIGITAL DC INPUT BOARD

SPECIFICATIONS

Board Size:

Length:	6.50"
Height:	4.25"
Width:	0.80"

Number of Inputs:

16

Input Voltage:

Vin(on-min):	10.0 volts
Vin(on-max):	30.0 volts
Vin(off-min):	5.0 volts

Input Current (max):

15 milliamps at Vin=30volts

Input Filter Delay:

typ delay:	0.50 milliseconds
min delay:	0.35 milliseconds
max delay:	0.80 milliseconds

Optical Isolation:

1500 Vrms

Power Requirements:

Icc (typ - M4500 BUS):	50 milliamps
------------------------	--------------


Temperature Ranges:

Storage:	0 to 85 degrees C
Operating:	0 to 60 degrees C

Relative Humidity:


5 to 95% non-condensing

APPENDIX A S4563: DIGITAL DC INPUT BOARD



Typical User Wiring

Board Outline



Typical Input Circuit

S4568: DIGITAL DC I/O BOARD
8-IN/8-OUT 10-30VDC SOURCING

FEATURES

- 8 Digital Input Points And 8 Digital Output Points
- 16 Individual Status LED's (1 Led Per Input Point)
- 0.5 Amp Drive Capability Per Output Point
- Output Transient Protection
- Removable Field Wiring Connector
- Optical Isolation
- Standard M4500 I/O Form Factor

GENERAL DESCRIPTION

The S4568 10-30VDC I/O Board, for use with the M4500 series of modules, contains 8 digital inputs and 8 digital outputs. One-half of the board utilizes the circuitry of an S4563 10-30VDC input board while the other half utilizes the circuitry of an S4573 10-30VDC output board.

The Input section contains 8 identical solid state input circuits which accept the on/off status of user devices such as push-buttons, limit switches, and proximity sensors. The inputs sense the voltage levels of digital DC input signals, with the devices driving the inputs being defined as sourcing (positive current into the input). When the voltage at the input is high (above the input "on" threshold), the input is read as a "1". When the input is low (approximately zero), the input is read as a "0". The on/off status of each input is indicated with individual LED's located on the front of the board. The LED's provide the status of the actual input points (field side) rather than the internal logic status.

APPENDIX A

S4568: DIGITAL DC I/O BOARD

The output section contains 8 identical solid state circuits which convert the logic status of a byte, written from the M4500 processor, to the appropriate voltage in order to drive user devices such as solenoids, relays, and lamps. On any given output point, writing a "1" to the point turns the output "on"; writing a "0" turns the output "off". When the output is "on", the voltage at the output is high (approximately equal to the user's supply voltage). When the output is "off", the voltage at the output is low (approximately zero). An output will "source" current to the load when "on", thus the outputs are defined as "sourcing".

Each output is rated at 0.5 amp DC (continuous) with an inrush (pulsed) current drive capability of 3 amps for 100msec. The sum of all outputs current cannot, however, exceed 6 amps continuous. The S4568 does not contain output fusing, therefore external fusing at each output point and at the user's Vcc connection point should be provided. Each output contains a transient suppression circuit which clamps any transient over voltage to a level that will not damage the output circuitry. This allows solenoids and other inductive loads to be connected directly to an output point without connecting "fly-back" diodes or other surge suppression devices to the load itself. Outputs may be "collector OR'd" such that applying 10-30VDC to an "off" output will not damage the output.

The on/off status of each output is indicated with individual LED's located on the front of the board. The LED's provide the status of the actual output points (field side) rather than the internal logic status. A given LED shows the correct status of the respective output point whether or not a load is connected to the output. No minimum load is required for proper output operation. Input, output and user power wiring is implemented with a removable 18-pin field wiring connector which allows easy board replacement.

The 8 input points are read in the least significant byte of the slot that the board is addressed as. Inputs 0 through 7 are mapped in bits 0 through 7 of byte 0 of the slot. The 8 output points are mapped in byte 1 of the slot that the board is addressed as. Outputs 10 through 17 are mapped in bits 0 through 7 of byte 1 of the slot.

INSTALLATION

Prior to installing the S4568, the I/O slot addressing dip switch on the board must be set for the slot the board will be addressed as.

Note: Geographical addressing is not used in the M4500. The slot the S4568 is addressed as is solely defined by the dip switch settings on the S4568 itself not by the slot in the M4500 chassis that the board is placed in. Two poles on the dip switch of the board set the binary slot address of the board as follows:

S4568 SW1 Dip Switch Slot Addressing

<u>2</u>	<u>1</u>	<u>Slot Address</u>
off	off	0
off	on	1
on	off	2
on	on	3

The SW1 Slot address dip switch is located in the lower left hand corner of the component side of the S4568. The respective switch pole is "on" when in either the "on" or "close" position and "off" when either in the "off" or "open" position depending on the type of dip switch used.

To install the S4568 in the M4500 chassis, turn power to the M4500 "off" and remove the cover plate of the M4500 by loosening the captive screws that retain it. Install the S4568 in the respective slot of the M4500, making sure the DIN connector on the S4568 fully mates with the DIN connector in the M4500 motherboard and that the top of the S4568 is seated correctly in the card guides at the top of the M4500. Install the M4500 cover back onto the M4500 making sure the LED's and Field connector protrude through the respective openings in the cover. The M4500 cover will retain the S4568 both from the top and the front, holding the S4568 in place during normal operation. Tighten the captive screws that retain the cover on the M4500. Install the female field wiring connector to the corresponding male connector on the S4568. The S4568 is now installed and ready to run. To remove the S4568, simply perform the previous steps in reverse.


APPENDIX A

S4568: DIGITAL DC I/O BOARD


SPECIFICATIONS

Board Size:	
Length:	6.50"
Height:	4.25"
Width:	0.80"
Number of Inputs:	8
Input Voltage:	
Vin(on-min):	10.0 volts
Vin(on-max):	30.0 volts
Vin(off-min):	5.0 volts
Input Current (max):	15 milliamps at Vin=30volts
Input Filter Delay:	
typ delay:	0.50 milliseconds
min delay:	0.35 milliseconds
max delay:	0.80 milliseconds
Number of Outputs:	8
Output Voltage:	
Voltage Range:	10-30VDC
Vout (on-min):	VCC-2.00 volts
Vout (on-max):	VCC-0.25 volts
Vout (off-min):	1.5 volts
Output Current:	
Iout (on max - continuous):	0.5 amps DC
Iout (on max - pulsed):	3.0 amps DC (for 100msec)
Iout (off max - leakage):	100 microamps
Output Response Time:	
max on time:	50 microseconds
max off time:	75 microseconds
Optical Isolation:	1500 Vrms
Power Requirements:	
Icc (typ - M4500 BUS):	50 milliamps
Temperature Ranges:	
Storage:	0 to 85 degrees C
Operating:	0 to 60 degrees C
Relative Humidity:	5 to 95% non-condensing

APPENDIX A
S4568: DIGITAL DC I/O BOARD




Typical User Wiring




Board Outline

APPENDIX A

S4568: DIGITAL DC I/O BOARD



Typical Input Circuit



Typical Output Circuit

S4573: DIGITAL DC OUTPUT BOARD
16-POINT 10-30VDC SOURCING

FEATURES

- 16 Digital Output Points
- 16 Individual Status LED's (1 Led Per Output Point)
- 0.5 Amp Drive Capability Per Output Point
- Output Transient Protection
- Removable Field Wiring Connector
- Optical Isolation
- Standard M4500 I/O Form Factor

GENERAL DESCRIPTION

The S4573 10-30VDC Output Board, for use with the M4500 series of modules, contains 16 identical solid state circuits which convert the logic status of 2 bytes, written from the M4500 processor, to the appropriate voltage in order to drive user devices such as solenoids, relays, and lamps. On any given output point, writing a "1" to the point turns the output "on"; writing a "0" turns the output "off". When the output is "on", the voltage at the output is high (approximately equal to the user's supply voltage). When the output is "off", the voltage at the output is low (approximately zero). An output will "source" current to the load when "on", thus the outputs are defined as "sourcing".

Each output is rated at 0.5 amp DC (continuous) with an inrush (pulsed) current drive capability of 3 amps for 100msec. The sum of all outputs current cannot, however, exceed 6 amps continuous. The S4573 does not contain output fusing, therefore external fusing at each output point and at the user's Vcc connection point should be provided. Each output contains a transient suppression circuit which clamps any transient over voltage to a level that will not damage the output circuitry. This allows solenoids and other inductive loads to be connected directly to an output point without connecting "fly-back" diodes or other surge suppression devices to the load itself. Outputs may be "collector OR'd" such that applying 10-30VDC to an "off" output will not damage the output.

APPENDIX A

S4573: DIGITAL DC OUTPUT BOARD

The on/off status of each output is indicated with individual LED's located on the front of the board. The LED's provide the status of the actual output points (field side) rather than the internal logic status. A given LED shows the correct status of the respective output point whether or not a load is connected to the output. No minimum load is required for proper output operation. Output and user power wiring is implemented with a removable 18-pin field wiring connector which allows easy board replacement.

The 16 output points are mapped in the two least significant bytes of the slot that the board is addressed as. Outputs 0 through 7 are mapped in bits 0 through 7 of byte 0 of the slot, while Outputs 10 through 17 are mapped in bits 0 through 7 of byte 1 of the slot.

INSTALLATION

Prior to installing the S4573, the I/O slot addressing dip switch on the board must be set for the slot the board will be addressed as.

Note: Geographical addressing is not used in the M4500. The slot the S4573 is addressed as is solely defined by the dip switch settings on the S4573 itself not by the slot in the M4500 chassis that the board is placed in. Two poles on the dip switch of the board set the binary slot address of the board as follows:

S4573 SW1 Dip Switch Slot Addressing

<u>2</u>	<u>1</u>	<u>Slot Address</u>
off	off	0
off	on	1
on	off	2
on	on	3

The SW1 Slot address dip switch is located in the lower left hand corner of the component side of the S4573. The respective switch pole is "on" when in either the "on" or "close" position and "off" when either in the "off" or "open" position depending on the type of dip switch used.

APPENDIX A

S4573: DIGITAL DC OUTPUT BOARD

To install the S4573 in the M4500 chassis, turn power to the M4500 "off" and remove the cover plate of the M4500 by loosening the captive screws that retain it. Install the S4573 in the respective slot of the M4500, making sure the DIN connector on the S4573 fully mates with the DIN connector in the M4500 motherboard and that the top of the S4573 is seated correctly in the card guides at the top of the M4500. Install the M4500 cover back onto the M4500 making sure the LED's and Field connector protrude through the respective openings in the cover. The M4500 cover will retain the S4573 both from the top and the front, holding the S4573 in place during normal operation. Tighten the captive screws that retain the cover on the M4500. Install the female field wiring connector to the corresponding male connector on the S4573. The S4573 is now installed and ready to run. To remove the S4573, simply perform the previous steps in reverse.

APPENDIX A

S4573: DIGITAL DC OUTPUT BOARD

SPECIFICATIONS

Board Size:

Length:	6.50"
Height:	4.25"
Width:	0.80"

Number of Outputs:

16

Output Voltage:

Voltage Range:	10-30VDC
Vout (on-min):	VCC-2.00 volts
Vout (on-max):	VCC-0.25 volts
Vout (off-min):	1.5 volts

Output Current:

Iout (on max - continuous):	0.5 amps DC
Iout (on max - pulsed):	3.0 amps DC (for 100msec)
Iout (off max - leakage):	100 microamps

Output Response Time:

max on time:	50 microseconds
max off time:	75 microseconds

Optical Isolation:

1500 Vrms

Power Requirements:

Icc (max - M4500 BUS):	125 milliamps (all outputs "on")
Icc (min - M4500 BUS):	35 milliamps (all outputs "off")


Temperature Ranges:

Storage:	0 to 85 degrees C
Operating:	0 to 60 degrees C

Relative Humidity:


5 to 95% non-condensing

APPENDIX A S4573: DIGITAL DC OUTPUT BOARD



Typical User Wiring

Board Outline



Typical Output Circuit


APPENDIX A

S4573: DIGITAL DC OUTPUT BOARD


(This Page Intentionally Left Blank)

APPENDIX B


RS-232 PINOUTS/CABLES



PROG Port Pin Out



DB9 (com1) to PROG Port Cable



DB25 (com1) to PROG Port Cable


APPENDIX B

RS-232 PINOUTS/CABLES

(This Page Intentionally Left Blank)

APPENDIX C

FIELD WIRING CONNECTOR PINOUTS



APPENDIX C

FIELD WIRING CONNECTOR PINOUTS

(This Page Intentionally Left Blank)